

<b>Issuing Authority:</b>	<b>Owner:</b>	<b>Project:</b>
ITSO	Technology at ITSO	Technical
<b>Document number:</b>	<b>Part Number:</b>	<b>Sub-Part Number:</b>
ITSO TS 1000	4	
<b>Issue number (stage):</b>	<b>Month:</b>	<b>Year:</b>
2.1.5	March	2025
<b>Title:</b>		
ITSO TS 1000-4 <i>Interoperable public transport ticketing using contactless smart customer media – Part 4: HOPS</i>		
<b>Replaces Documents:</b>		
ITSO TS 1000-4 2010-02 issue number 2.1.4		

## Revision history of current edition

Date	ITSO Ref.	Editor ID	Nature of Change to this Document (or Part)
Feb 2003		PQ	Document created
May 2003		PQ	Amended after editorial review
June 2003		PQ	Released for issue as CD.
Aug 2003		JW/CS/PJ	Amended after review by TC & Authors. Issued as 2 <sup>nd</sup> CD.
Nov 2003		PJ/JW	Amended with comments received
Nov 2003		SLB	Editorial changes only. Issue 1 <sup>st</sup> consultation draft.
Jan 2004		JC	Implement DRC changes.
Feb 2004		JW	Check/consolidate DRC changes.
Feb 2004		SLB	Clean up and format as final draft.
Mar 2004		SLB	Implement final changes and prepare for issue.
Oct 2006		MPJE	Updated to include ISADs following approval by DfT
April 2007		PRJ	Updated to include ISADs following approval by DfT
Jun 2007		MPJE	Final Editing prior to publication
Feb 2008		PRJ	Updated to include ISADs following approval by DfT
Apr 2008		MPJE	Final Editing prior to publication
Dec 2009		PRJ	Updated to include ISADs following approval by DfT
Feb 2010		MPJE	Final Editing prior to publication
Apr 2015		MPJE	Updated to incorporate Corrigendum 9 to Version 2.1.4
May 2024		AM	Draft publication of Version 2.1.5
Mar 2025		AM	Updated to include ISADs following approval by DfT.
Mar 2025		AM	Final Editing prior to publication of Version 2.1.5

**Document Reference: ITSO TS 1000-4**

**Date: 2025-03-31**

**Version: 2.1.5**

**Ownership: ITSO**

**Secretariat: Technology at ITSO**

# **ITSO Technical Specification 1000-4 – Interoperable Public Transport Ticketing using contactless smart customer media – Part 4: HOPS**

**ISBN: 978-1-3999-8707-3**

Although this information was commissioned by the Department for Transport (DfT), the specifications are those of the authors and do not necessarily represent the views of the DfT. The information or guidance in this document (including third party information, products and services) is provided by DfT on an 'as is' basis, without any representation or endorsement made and without warranty of any kind whether express or implied.



© King's Printer and Controller of His Majesty's Stationery Office (HMSO), 2025, except where otherwise stated.

Copyright in the typographical arrangement rests with the Crown.

You may re-use this information (not including logos or third-party material) free of charge in any format or medium, under the terms of the Open Government Licence v3.0. To view this licence visit <http://www.nationalarchives.gov.uk/doc/open-government-licence/version/3> or write to the Information Policy Team, The National Archives, Kew, London TW9 4DU, or e-mail: [psi@nationalarchives.gsi.gov.uk](mailto:psi@nationalarchives.gsi.gov.uk).

## Foreword

This document is a part of ITSO TS 1000, a Specification published and maintained by ITSO, a membership company limited by guarantee without shareholders. The membership of ITSO comprises transport organisations, equipment and system suppliers, local and national government. For the current list of members see the ITSO web site [www.itso.org.uk](http://www.itso.org.uk)

ITSO TS 1000 is the result of extensive consultation between transport providers, sponsors, system suppliers and manufacturers. The Department for Transport (DfT) has also contributed funding and expertise to the process.

Its purpose is to provide a platform and tool-box for the implementation of interoperable contactless smart customer media public transport ticketing and related services in the UK in a manner which offers end to end loss-less data transmission and security. It has been kept as open as possible within the constraints of evolving national, European and International standards in order to maximise competition in the supply of systems and components to the commercial benefit of the industry as a whole. In general, it promotes open standards but it does not disallow proprietary solutions where they are offered on reasonable, non-discriminatory, terms and contribute towards the ultimate objective of interoperability.

ITSO has been established to maintain the Technical Specification and Business Rules required to facilitate interoperability. It also accredits participants and interoperable equipment. ITSO is a facilitator of interoperability at the minimum level of involvement necessary. It will not involve itself in any commercial decisions or arrangements for particular ticketing schemes; neither will it set them up nor run them. It will however “register” them in order to provide the necessary interoperability services (e.g. issue and control of unique scheme identifiers, certification and accreditation, security oversight).

Consequently, adoption of this Specification for particular ticket schemes will be a matter for the commercial judgement of the sponsors/participants, as will the detailed Business Rules and precise partnership arrangements.

## Contents

Revision history of current edition .....	2
Foreword .....	4
Contents .....	5
1. Scope .....	9
1.1 Scope of Part 4 .....	9
2. Host Operator or Processing System (HOPS) Overview .....	10
2.1 HOPS Components and Functions .....	10
2.2 HOPS configurations .....	11
2.3 HOPS functionality required by the Licensed Member roles .....	12
2.3.1 Shell Ownership .....	12
2.3.2 Shell Retailer .....	13
2.3.3 Collection and Forwarding .....	13
2.3.4 Product Ownership .....	14
2.3.5 Product Retailer .....	14
2.3.6 Service Operator .....	15
2.4 HOPS User Functions .....	15
2.5 HOPS data .....	16
3. Communications .....	17
3.1 External interfaces .....	17
3.2 Loss Less Communications .....	17
4. HSAM .....	18
5. The Message Store .....	19
6. Message Processor .....	20
6.1 Message Processor overview .....	20
6.1.1 General .....	20
6.1.2 Loss Less communication .....	20
6.1.3 Virtual Private Network (VPN) and Extensive Mark-up Language (XML) .....	20
6.2 External entities .....	20
6.2.1 Point Of Service Terminals (POSTs) .....	20
6.2.2 Host Operator or Processing System (HOPS) .....	22
6.2.3 ITSO Security Management Service (ISMS) .....	25
6.3 Internal client components .....	27
6.3.1 Accounts .....	27
6.3.2 Services .....	27
6.3.3 AMS .....	28
6.4 Internal resource components .....	29
6.4.1 HSAM .....	29
6.4.2 Message Store .....	29
7. ITSO Shell Accounts (ISA) and ITSO Product Accounts (IPA) .....	30

7.1 Account Types.....	30
7.2 The ITSO Shell Account (ISA).....	30
7.2.1 General .....	30
7.2.2 Data requirements .....	30
7.2.3 ISA History Data Store.....	31
7.2.4 Managing the ITSO Shell Account (ISA) .....	32
7.3 ITSO Product Accounts (IPA).....	32
7.3.1 Stored Travel Rights (STR) IPA; relating to IPE TYP 2.....	32
7.3.2 Charge To Account (CTA) IPA; relating to IPE TYPs 4 and 5.....	33
7.3.3 Loyalty IPA, relating to IPE TYPs 3 and 17 .....	34
7.3.4 ITSO ID IPA .....	35
7.3.5 Entitlement IPA .....	37
7.3.6 Ticket and Similar Product IPAs .....	38
7.4 Account Processing.....	40
7.4.1 User access to accounts.....	40
7.4.2 General Account processing.....	40
7.4.4 STR Auto-Top-Up operation .....	40
7.4.5 STR Actionlist top up .....	40
7.4.6 STR scheme exposure .....	41
7.4.7 STR Negative Balance.....	41
7.4.8 Handling STR Add-Value Records .....	41
7.4.9 CTA IPA processing.....	41
7.4.10 Auto-Renew .....	41
7.5. List Processing .....	41
7.5.1 Creating Lists .....	42
7.5.2 Hotlists .....	42
7.5.3 Actionlists .....	43
7.6. Loyalty schemes.....	45
7.6.1 Loyalty scheme types .....	45
7.6.2 Loyalty scheme operation.....	45
7.6.3 Deferred Use Loyalty IPEs.....	45
7.7 IPE Embodiment Specifications .....	45
8. Asset Management System (AMS).....	46
8.1 AMS overview.....	46
8.1.1 General .....	46
8.1.2 ISMS interface .....	46
8.2 Physical ISAM / HSAM.....	47
8.2.1 General .....	47
8.2.2 POST allocation .....	47
8.2.3 HOPS allocation.....	48

8.2.4 ISAM / HSAM state .....	48
8.2.5 ISAM / HSAM memory management.....	48
8.2.6 ISAM grouping .....	50
8.3 Centrally controlled Acceptance and Capability Criteria tables.....	51
8.4 Locally controlled Acceptance and Capability Criteria tables.....	51
8.4.1 ISAM Configuration .....	52
8.4.2 Physical ISAM Groups .....	52
8.4.3 IPEs Accepted .....	52
8.4.4 Criteria.....	53
8.4.5 Limits List .....	53
8.5 POST stored POST configuration data .....	54
8.5.1 Term Dates .....	54
8.5.2 Peak times .....	54
8.5.3 Day type assignment .....	54
8.5.4 Transfers .....	54
8.5.5 Rebates.....	54
8.5.6 Loyalty.....	54
8.5.7 Exchange rates .....	54
8.5.8 Zones .....	55
8.5.8a Zone Table Bitmap.....	55
8.5.9 Sale price .....	55
8.5.10 IIN index.....	55
8.5.11 IPE Embodiment parameters.....	55
8.5.12 ISAM Management File Parameters.....	55
8.5.13 Passback Times.....	55
8.5.14 HOPS PCD and Manifest application rules .....	55
8.5.15 Sending of PCD from a HOPS.....	56
8.6 AMS interfaces .....	57
8.6.1 ISMS .....	58
8.6.2 Managed ISAMs .....	70
8.6.3 Managed POSTs .....	71
8.6.4 Asset administrator .....	71
8.7 Functionality .....	71
8.7.1 Installation / commissioning of ISAMs .....	72
8.7.2 Create ISAM Physical Groups .....	72
8.7.3 Change ISAM Physical Group .....	73
8.7.4 Take an ISAM out of service.....	73
8.7.5 Reinstate an ISAM into service.....	73
8.7.6 Make changes to ISAM Data .....	74
8.7.7 Introduction of new product into scheme .....	74

8.7.8 Withdrawal of a product .....	74
8.7.9 Enabling of a new Customer Media platform .....	75
8.7.10 Update of Directory keys by ITSO Registrar .....	75
8.7.11 Update of Transaction keys by / HSAM Registrar .....	75
8.7.12 Support of regular key rollover .....	75
8.7.13 Removal of an ITSO member .....	76
8.7.14 Change ISAM password parameters .....	76
8.7.15 Change storage of transactions parameters .....	76
8.7.16 ISAM Parameter Table Request and Response message codes 080A and 080B .....	76
9. Services .....	77
9.1 Audit Trail .....	77
9.2 Error Log .....	77
9.3 Journal .....	77
9.4 Query Facility .....	77
9.5 ITSO Regulation Compliance Monitoring. ....	78
9.6 Security Monitoring. ....	78
9.7 User Access Control .....	78
9.8 Data Backup and Archiving .....	78
9.9 System Clock .....	79



## 1. Scope

ITSO TS 1000 defines the key technical items and interfaces that are required to deliver interoperability. To this end, the end-to-end security system and ITSO Shell layout are defined in detail; while other elements (e.g. terminals, 'back-office' databases) are described only in terms of their interfaces. The business rules that supplement the technical requirements are defined elsewhere.

### 1.1 Scope of Part 4

This Part of the ITSO Specifications, ITSO TS 1000-4, defines the requirements of the ITSO Host Operator or Processing System (HOPS).

The HOPS modules described in this part are:

- HSAM
- Message Store
- Message Processing
- Asset Management (AMS)
- ITSO Shell Accounts (ISA)
- Product Accounts
- Services

Only requirements that are pertinent to Interoperable Smart Customer Media (CM) usage and interfacing to other parts of the ITSO Environment are defined in this document. This document does not define non-ITSO requirements, many of which may be essential to procure a functional ticketing system.

## 2. Host Operator or Processing System (HOPS) Overview

A HOPS is defined as any entity where the ITSO data is processed, but excluding any entity which simply acts as a 'Store and Forward' node.

All HOPS shall contain the mandatory components defined in subsequent clauses, that is the HSAM, Message Processing function, Message Store and Services functions as shown in figure 1.

All ITSO Compliant Schemes shall provide all the components defined in subsequent clauses, as shown in figure 1, but not necessarily in the same HOPS.




Figure 1 - HOPS overview

### 2.1 HOPS Components and Functions

The major components and functions of the HOPS are:

HSAM

Message Store:

- Secure storage of all ITSO data messages transmitted and received;

Message Processing:

- Receiving and processing data and command messages from POSTs, ISMS and other HOPS
- Sending data and command messages to POSTs, ISMS and other HOPS
- Forwarding not-on-us transactions to other HOPS
- HSAM interface
- Passing received data to the HSAM for integrity checking
- Passing data for transmission to the HSAM for signing

- Managing the Loss Less transmission process in conjunction with the HSAM
- Managing HSAM configuration
- Handling ISAM configuration files
- Making on-us data available to other HOPS functions
- Storing all message data in the Message Store

Asset Management (AMS):

- Recording status and disposition of all managed POSTs, ISAMs and HSAMs
- Interface with the ISMS
- Provision of ISMS generated configuration & key files to POST ISAMs
- Provision of AMS generated configuration files to POST ISAMs
- Management of ITSO Compliant Scheme POST configuration files
- Managing ISAM acknowledgements destined for AMS or ISMS

Accounts:

- ITSO Shell Accounts
- ITSO Product Accounts
- List Processing
- Hotlist Management
- Actionlist Management

Services:

- Adding to and managing access to the audit trail and journal
- Rule compliance monitoring
- Security monitoring
- Backup facilities
- Archival facilities

Ticketing System Configuration.

## 2.2 HOPS configurations

All HOPS shall contain the following mandatory components:

- Message Processing
- Services
- HSAM; and
- Message Store

A HOPS may include the following optional components:

- AMS
- Accounts
- Ticketing System Configuration

An individual ITSO Compliant Scheme may use a single HOPS, multiple HOPS or share capacity in a HOPS.

The optional AMS and Accounts components shall be provided in each and every ITSO Compliant Scheme.

## 2.3 HOPS functionality required by the Licensed Member roles

ITSO defines the following key functions that Licensed Members shall fulfil:

- Application Issuing
  - Shell Ownership
  - Shell Retailing
- Collection and Forwarding
- Product Ownership
- Product Retailing
- Service Operating

Each of the above will require the use of a HOPS<sup>1</sup>, although the configuration and feature set will differ as outlined below.

Note 1: The Shell Ownership and Shell Retailer roles defined in 2.3.1 and 2.3.2 are combined in the ITSO Business Rules into a single Application Issuing role.

Note 2: In some circumstances, a Licensed Member provides a HOPS which, of necessity, contains an HSAM but does not manage ISAMs for any other purpose. For example, this is the case for a Shell Owner who does not perform any other ITSO function. In these circumstances, the services of an AMS are required to manage the HSAM. Where the HOPS does not include this functionality, a commercial relationship is required with another Licensed Member who will provide the AMS functionality necessary to enable the HSAM.

### 2.3.1 Shell Ownership

The Shell Ownership function is defined as specifying the pricing, usage and commercial rules relating to the loading and use of Instances of a particular ITSO Shell.

In order to carry out the above function the Shell Owner shall be able to define and register the attributes of the Shell with the ITSO Registrar.

The Shell Owner shall maintain an ITSO Shell Account (ISA) for each instance of Shell issued.

The HOPS configuration as used by a Shell Owner shall include:

• HSAM	(Mandatory component)
• Message Store	(Mandatory component)
• Message Processing	(Mandatory component)
• Services	(Mandatory component)
• Asset Management (AMS)	For management of HSAMs only <sup>2</sup>
• ITSO Shell Accounts (ISA)	For management of instances of Shells issued
• ITSO Product Accounts (IPA)	Not required
• List processing	For management of instances of Shells issued

<sup>1</sup> Either owner and operated by the Licensed Member, or provided in the form of a contracted service by a 3rd party to that Licensed Member.

<sup>2</sup> Shell Ownership does not involve the more complex function of managing subservient ISAMs

### 2.3.2 Shell Retailer

The Shell Retailer function is defined as loading Shell Instances onto Customer Media or issuing Customer Media to Customers, where the Media contains a Shell.

In order to carry out the above function the Shell Retailer shall require equipment to encode the Shell onto the media. This encoding equipment must contain an ISAM (i.e. the equipment shall be certified as a POST)

The Shell Retailer will obtain the required Shell embodiment parameters and security keys from the ISMS for which they are authorised by the Shell Owner.

The HOPS configuration as used by a Shell Retailer shall include:

• HSAM	(Mandatory component)
• Message Store	(Mandatory component)
• Message Processing	(Mandatory component)
• Services	(Mandatory component)
• Asset Management (AMS)	For management of HSAMs and ISAMs in encoding equipment only
• ITSO Shell Accounts (ISA)	Not required
• ITSO Product Accounts (IPA)	Not required
• List processing	For list management / targeting

### 2.3.3 Collection and Forwarding

The Collection and Forwarding function is defined as collecting Transaction Data relating to the loading or use of the Product Instances from Product Retailers and Service Operators, receiving Transaction Data from other Collection and Forwarding Operators including Shell, Product and security data, forwarding On Us Data to the relevant Product Owners and Not On Us Data to the relevant other Collection and Forwarding Operators.

In order to carry out the above function the Collection and Forwarding entity must receive and transmit ITSO messages from POSTs and other Collection and Forwarding entities. The handling of these messages has certain requirements to ensure that the end-to-end transmission is Loss-less.

The core functionality of a HOPS is the handling of ITSO messages. The HOPS configuration as used by a Collection and Forwarding entity shall include:

• HSAM	(Mandatory component)
• Message Store	(Mandatory component)
• Message Processing	(Mandatory component)
• Services	(Mandatory component)
• Asset Management (AMS)	For management of HSAM(s) only <sup>3</sup>
• ITSO Shell Accounts (ISA)	Not required
• ITSO Product Accounts (IPA)	Not required

<sup>3</sup> Collection and Forwarding does not involve the more complex function of managing subservient ISAMs

• List processing	Not required
-------------------	--------------

### 2.3.4 Product Ownership

The Product Ownership function is defined as specifying the pricing, usage and commercial rules relating to the loading and use of Product Instances of a particular ITSO Product.

In order to carry out the above function the Product Owner must be able to define and register the attributes of the product with the ITSO Registrar.

Note: The Product Owner shall define and register the applicable commercial arrangements between himself and Product Retailers / Service Operators in accordance with the ITSO Business Rules. The Product Owner shall maintain an ITSO Product Account (IPA) for each instance of product issued.

The HOPS configuration as used by a Product Owner shall include:

• HSAM	(Mandatory component)
• Message Store	(Mandatory component)
• Message Processing	(Mandatory component)
• Services	(Mandatory component)
• Asset Management (AMS)	For management of HSAM(s) only <sup>4</sup>
• ITSO Shell Accounts (ISA)	Not required
• ITSO Product Accounts (IPA)	For management of instances of products issued
• List processing	For management of instances of products issued

### 2.3.5 Product Retailer

The Product Retailer function is defined as loading Product Instances onto Media held by Customers.

In order to carry out the above function the Product Retailer will require equipment to encode the IPE onto the media. This encoding equipment must contain an ISAM (i.e. the equipment shall be certified as a POST)

The Product Retailer will obtain the required IPE embodiment parameters and security keys from the ISMS for which they are authorised by the Product Owner.

The HOPS configuration as used by a Product Retailer shall include:

• HSAM	(Mandatory component)
• Message Store	(Mandatory component)
• Message Processing	(Mandatory component)
• Services	(Mandatory component)
• Asset Management (AMS)	For management of ISAMs in encoding equipment
• ITSO Shell Accounts (ISA)	Not required

---

<sup>4</sup> Product Ownership does not involve the more complex function of managing subservient ISAMs

• ITSO Product Accounts (IPA)	Not required
• List processing	For list management / targeting

### 2.3.6 Service Operator

The Service Operator function is defined as providing services to Customers who use the Product Instances loaded onto Media held by them as their entitlement to obtain such services.

In order to carry out the above function the Service Operator will require (POST) equipment to transact with the IPE held on the media. This equipment must contain an ISAM.

The Service Operator will obtain the required security keys from the ISMS.

The HOPS configuration as used by a Service Operator shall include:

• HSAM	(Mandatory component)
• Message Store	(Mandatory component)
• Message Processing	(Mandatory component)
• Services	(Mandatory component)
• Asset Management (AMS)	For management of ISAMs in POSTs
• ITSO Shell Accounts (ISA)	Not required
• ITSO Product Accounts (IPA)	Not required
• List processing	For list management / targeting

## 2.4 HOPS User Functions

The HOPS shall provide user access to HOPS functions to accomplish the following tasks:

- Enter Hotlist and Actionlist commands, compile and distribute to POSTs, Set up destinations for the lists
- Amend ITSO Shell, ITSO Product Accounts (IPA) and associated Customer Media data as required to accomplish the functions described below, e.g. Auto-Top-Up levels
- Create and maintain POST configuration data
- Create, maintain and distribute local ITSO Compliant Scheme specific ISAM data using AMS secure messaging
- Create and amend AMS data as subsequently described
- Other system configuration functions necessary for the correct operation of the HOPS, e.g. POST polling times, transaction processing run start times, etc
- Action the AMS to send commands to ISMS, POSTs or other HOPS as required. Provide a facility to create ISAM scripts for the ISMS to send to ISAMs or HSAM
- Run programs to examine message store records for integrity, validity, consistency, continuity or for unusual usage patterns
- Search/Report on Message Store, Audit Trail, Journal, as described below
- Set up and manipulate loyalty schemes
- Set up and control the Charge to Account(CTA) accounts
- Requesting allocation of ISAMs from the ISMS

- Ad-hoc reporting on system health
- Error reporting, viewing and administrative functions and
- Ticketing system configuration

The HOPS shall be able to allow or deny users access to these functions by using the permissions system described in subsequent clauses.

## 2.5 HOPS data

ITSO does not prescribe how the HOPS should store data, so each supplier may implement data stores appropriate to their needs<sup>5</sup>.

The HOPS shall provide and/or limit access to various data as described in subsequent clauses.

The HOPS shall meet all the requirements herein relating to data retention, data protection, data backup and data archiving. In particular, the HOPS shall take note of the requirements of the General Data Protection Regulation (GDPR) when storing personal data.

Note: User functions need only be provided where the associated HOPS component is included in the implementation.

---

<sup>5</sup> For this reason, henceforth in this document the term data store is used in preference to database



### **3. Communications**

#### **3.1 External interfaces**

The HOPS shall interface to the following external components:

- The ISMS (if AMS functionality provided on this HOPS)
- POSTs
- Intermediate nodes such as Depot or Station computers with which the HOPS must communicate in order to communicate with a remote POST
- Other HOPS and
- Any governance system mandated by the ITSO Operators Licence

#### **3.2 Loss Less Communications**

All HOPS shall support 2-way loss-less communications with:

- POSTs
- Other HOPS
- The ISMS

The HOPS shall comply fully with the communications requirements defined in ITSO TS 1000-9.

## 4. HSAM

Every HOPS shall be fitted with an HSAM<sup>6</sup>.

Each and every HSAM type or configuration shall be certified by ITSO as suitable for use in a HOPS.

Each HSAM shall be registered by the ITSO Security Management Service (ISMS).

The OID data element within the HSAM ID shall be used to identify the HOPS in ITSO Application Messages generated by the HOPS to other nodes.

The format of the ISAM ID number is defined in ITSO TS 1000-2.

The HOPS shall provide a software interface to the HSAM.

The capability and use of the HSAM is defined in ITSO TS 1000-7 and ITSO TS 1000-8.

HSAMs shall always be installed in a Controlled Environment as defined in TS1000-9 clause 11.2.5.

The management of class 3 messages relating to the HSAM shall be identical to that defined for a POST ISAM, see TS 1000-3 clauses 6.3.7 and 6.3.8

---

<sup>6</sup> Refer to ITSO TS 1000-1 for the definition of HSAM

## 5. The Message Store

The HOPS shall include a Message Store.

The Message Store shall:

- Record in unaltered form all incoming and outgoing ITSO messages received or transmitted by the HOPS
- The messages shall be stored in the format in which they are received, and, if received in a non-ITSO format shall also be stored in ITSO transmission format
- Store all such messages for a minimum period of 2 years and 6 months from the commissioning date for any new HOPS and thereafter store all such messages for a minimum period of 1 year 4 months
- Include a facility to search and report on the message store. Resultant data extracts shall be presented in XML to facilitate auditing
- Be protected from any unauthorised addition, modification, renaming, moving or deletion
- Be protected from unauthorised access of any kind
- Message data shall be stored in non-volatile memory as immediately as reasonably practical, and in any event prior to handling of the next data message or within 2 seconds of completing transmission or reception of the message, whichever is the sooner
- The message data store shall comprise two separate non-volatile memory devices, where each device duplicates the other, i.e. each data item shall be stored twice, once in each data storage device

The Message Store data shall be included in the data set preserved by the HOPS backup and archive facilities.

The HOPS Message Store shall provide a search and reporting facility based on the categories described here individually or in combination:

- Date range
- Originating device ISAMID or HSAM identity
- ITSO message class
- ITSO message code
- Message direction
- On-us or not-on-us

## 6. Message Processor

The Message Processor is a mandatory component required in every instance of a HOPS.

### 6.1 Message Processor overview

#### 6.1.1 General

The Message Processor handles all ITSO messaging between the HOPS and the following external entities:

- POSTs
- HOPS
- ISMS

The Message Processor provides a service to the following internal components within a HOPS:

- Accounts
- Services
- AMS

The Message Processor makes use of the services of the following components within the HOPS:

- HSAM
- Message Store

Clauses 6.2 to 6.4 define these interfaces and functions in detail.

#### 6.1.2 Loss Less communication

All communications shall conform to the ITSO requirements for lossless data transfer. See ITSO TS 1000-9 for full details of this.

#### 6.1.3 Virtual Private Network (VPN) and Extensive Mark-up Language (XML)

All HOPS shall have the capability to communicate over a VPN running on the public Internet. This shall be used for communications to other HOPS and to the ISMS. A VPN may also be utilised for POST to HOPS, and HOPS to POST communications.

Data exchanged on the above link shall be formatted using XML and all HOPS shall support the use of both the full and the minimal tag set as defined in ITSO TS 1000-9.

## 6.2 External entities

Where two or more Destination data elements in a message are the same, a HOPS shall forward only one instance of a Data Frame to that destination.

### 6.2.1 Point Of Service Terminals (POSTs)

Communication with the POSTs under its control is a major role of the HOPS. The Message Processor shall handle these communications as defined in the following clauses.

#### 6.2.1.1 Message format and transmission method

All HOPS shall support the generation and transmission of messages to POSTs in the ITSO transmission format defined in ITSO TS 1000-9.

All HOPS shall support the receiving and processing of messages from POSTs in the ITSO transmission format defined in ITSO TS 1000-9.

HOPS may support other message formats to POSTs in addition to the ITSO defined transmission format, provided said formats:

- Support the loss-less data transmission methodology defined in ITSO TS 1000-9
- Allow the required data to be transmitted in a robust and secure manner
- Allow the transmitted data to be fully recovered to its native format

ITSO does not mandate the transmission method used between HOPS and POSTs / ticketing system. System designers may use any transmission method, provided said methods:

- Support the loss-less data transmission methodology defined in ITSO TS 1000-9
- Allow the required data to be transmitted in a robust and secure manner
- Allow the transmitted data to be fully recovered to its native format

Note: It is the Licensed Member's responsibility to ensure the confidentiality of operational data passed between these nodes. The ITSO Specification does not provide for confidentiality of data messages, i.e. encryption is not specified, with the exception of the ISRN which is encrypted to prevent CM holder movement tracking. Therefore, Licensed Members must decide whether they need to make the messages confidential or not and ensure that they comply with their responsibilities under the General Data Protection Regulation (GDPR). If confidentiality is required, then the Licensed Member must provide another layer of protection.

### 6.2.1.2 Message set

The Message Handler shall support the following message set from a POST to a HOPS:

• Transfer of ACK2 positive acknowledgements	Class 0
• Transfer of NAK2 positive acknowledgements	Class 0
• Transfer of Transaction Record Data Messages	Class 1
• Transfer of Queries	Class 2
• Transfer of user defined Data Frames	Class 2
• Transfer of Miscellaneous Messages	Class 2
• Transfer of ISAM Security Acknowledgements	Class 3

The Message Handler shall support the following message set from a HOPS to a POST:

• Transfer of ACK1 positive acknowledgements	Class 0
• Transfer of NAK1 positive acknowledgements	Class 0
• Transfer of ACK2 positive acknowledgements	Class 0
• Transfer of NAK2 positive acknowledgements	Class 0
• Transfer of Query Responses	Class 2
• Transfer of POST Configuration Data Lists	Class 2
• Transfer of Parameter Tables	Class 2

• Transfer of user defined Data Frames	Class 2
• Transfer of Miscellaneous Messages	Class 2
• Transfer of ISAM Security Files	Class 3

See ITSO TS 1000-9 for details of the different message classes.

See ITSO TS 1000-6 for a detailed list of the messages and their message codes.

### 6.2.1.3 Message security

The Message Processor shall verify the authenticity and integrity of all received messages from a POST in the manner defined in ITSO TS 1000-9.

The Message Processor shall verify the authenticity and integrity of all received Data Frames from a POST in the manner defined in ITSO TS 1000-9. It shall use the services of the HSAM to carry out said verification.

The Message Processor shall seal all Data Frames sent to a POST in the manner defined in ITSO TS 1000-9. It shall use the services of the HSAM to carry out said sealing.

The Message Processor shall store a copy of each and every received message from a POST in the Message Store prior to any processing of said message.

The Message Processor shall store a copy of each and every transmitted message to a POST in the Message Store.

### 6.2.1.4 Positive acknowledgements and routing

The Message Processor shall generate the required positive acknowledgements to received messages / Data Frames from a POST. See ITSO TS 1000-9 for details of the positive acknowledgement process.

The Message Processor shall re-transmit messages to the POST when a valid ACK is not received within the required period as defined in ITSO TS 1000-9.

The Message Processor shall route (forward on) messages received from a POST that it is not authorised to process. Said routing shall be in the manner defined in ITSO TS 1000-9.

### 6.2.1.5 Enveloping

The Message Processor shall support the enveloping of received messages / Data Frames from a POST. See ITSO TS 1000-9 for details of the enveloping process.

### 6.2.1.6 Transaction Session Batch management

The Message Processor shall manage the 'closing' and acknowledging of Transaction Session Batches as defined in ITSO TS 1000-9.

## 6.2.2 Host Operator or Processing System (HOPS)

To achieve interoperability, ITSO have defined an architecture whereby HOPS shall be able to exchange required data with other HOPS on a peer-to-peer basis. The Message Processor shall handle this communication as defined in the following clauses.

### 6.2.2.1 HOPS to HOPS Message format and transmission method

All HOPS shall support the generation and transmission of messages to HOPS in the ITSO transmission format defined in ITSO TS 1000-9.

All HOPS shall support the receiving and processing of messages from HOPS in the ITSO transmission format defined in ITSO TS 1000-9.

All HOPS shall support the generation and transmission of XML tagged message files as defined in ITSO TS 1000-9.

All HOPS shall support the receiving and processing of XML tagged message files as defined in ITSO TS 1000-9.

HOPS may support other inter-HOPS message formats in addition to the XML tagged and ITSO defined transmission formats provided said formats:

- Support the loss-less data transmission methodology defined in ITSO TS 1000-9;
- Allow the required data to be transmitted in a robust and secure manner;
- Allow the transmitted data to be fully recovered to its native format.

All HOPS shall provide support for transmission and receipt of message files via a VPN as defined in ITSO TS 1000-9.

HOPS may support other message file transmission methods in addition to the VPN, provided said methods:

- Support the loss-less data transmission methodology defined in ITSO TS 1000-9
- Allow the required data to be transmitted in a robust and secure manner
- Allow the transmitted data to be fully recovered to its native format

### 6.2.2.2 Message set

The Message Handler shall support the following inter-HOPS message set:

• Transfer of ACK2 positive acknowledgements	Class 0
• Transfer of NAK2 positive acknowledgements	Class 0
• Transfer of Queries	Class 2
• Transfer of Query Responses	Class 2
• Transfer of POST Configuration Data Lists	Class 2
• Transfer of Parameter Tables	Class 2
• Transfer of Data Correction Records	Class 2
• Transfer of Envelop Frames	Class 2
• Transfer of user defined Data Frames	Class 2
• Transfer of Miscellaneous Messages	Class 2
• Transfer of ISAM Security Files	Class 3
• Transfer of ISAM Security Acknowledgements	Class 3

See ITSO TS 1000-9 for details of the different message classes.

See ITSO TS 1000-6 for a detailed list of the messages and their message codes.

### **6.2.2.3 Message security**

The Message Processor shall verify the authenticity and integrity of all received messages from a HOPS in the manner defined in ITSO TS 1000-9.

The Message Processor shall verify the authenticity and integrity of all received Data Frames from a HOPS in the manner defined in ITSO TS 1000-9. It shall use the services of the HSAM to carry out said verification.

The Message Processor shall seal all Data Frames sent to a HOPS in the manner defined in ITSO TS 1000-9. It shall use the services of the HSAM to carry out said sealing.

The Message Processor shall store a copy of each and every received message from a HOPS in the Message Store prior to any processing of said message.

The Message Processor shall store a copy of each and every transmitted message to a HOPS in the Message Store.

### **6.2.2.4 Positive acknowledgements and routing**

The Message Processor shall generate the required positive acknowledgements to received messages / Data Frames from a HOPS. See ITSO TS 1000-9 for details of the positive acknowledgement process.

The Message Processor shall re-transmit messages to the (external) HOPS when a valid ACK is not received within the required period. This re-transmission shall be as defined in ITSO TS 1000-9.

The Message Processor shall route (forward on) messages received from a HOPS that it is not authorised to process. Said routing shall be in the manner defined in ITSO TS 1000-9.

### **6.2.2.5 Enveloping**

The Message Processor shall support the enveloping of received messages / Data Frames from a HOPS. See ITSO TS 1000-9 for details of the enveloping process.

### **6.2.2.6 Generation and Processing of Sequence Numbers in HOPS to HOPS Messages.**

When preparing class 2 Data Frames for transmission to another HOPS, the HOPS shall determine the Sequence Number (Seq#) as follows:

- The HOPS shall maintain separate Seq# registers for each possible originating OID and recipient OID combination, automatically creating these registers when the HOPS is required to send a Data Frame to a new recipient;
- When a Data Frame is sent from a particular originating OID to a particular recipient OID, then the Seq# register appropriate to the OID combination shall be used to give this Data Frame the next Seq# in sequence, and the register incremented by one (1).
- On first use of a Seq# register, the First Data Frame generated shall be allocated Seq# 0x000001.

### **6.2.2.7 Generation of Sequence Numbers in HOPS to POST Class 2 Messages.**

For class 2 Data Frames sent to POSTs, the transmitting HOPS shall maintain a single Seq# register, and shall simply use the next available value when preparing a Data Frame, irrespective of destination, incrementing the Seq# register by one (1) each time a Data Frame is prepared.

### **6.2.2.8 Processing of Sequence Numbers in Messages Received From Other HOPS**

When a HOPS receives a Data Frame from another HOPS, it shall process the Seq# as follows;

- The receiving HOPS shall maintain a record of Seq# values received from other HOPS, by OID value;



- The receiving HOPS shall check for gap in the sequence of Seq# values received from each other HOPS, indication that a Data Frame has not been received from that HOPS;
- If such a gap in the sequence exists for a configurable pre-defined period of time or more from receipt of the first Data Frame received after the missing Data Frame, then the HOPS shall:
  - Bring this to the attention of the HOPS owning Licensed Member and
  - Transmit a Data Frame Not Received Advisory (0913) message to the relevant transmitting HOPS.

The default value for the time period during which the HOPS will take no action before raising a warning of a gap in the Data Frame sequence shall be 48 hours.

A receiving HOPS, which has implemented node pair specific sequence numbering, will raise repeated errors when receiving Data Frames from a transmitting HOPS, certified to an earlier version of the Specification, and which has not implemented the method.

Therefore, receiving HOPS need to be aware of the capabilities of transmitting HOPS, and shall only enable the node pair specific sequence number check when it is known that the transmitting HOPS has implemented and is using the method. For this reason, receiving HOPS shall be capable of enabling or disabling the method separately for each transmitting HOPS from which it receives messages.

A receiving HOPS operator shall enable the method promptly as soon as a transmitting HOPS enables the method on an individual basis.

When enabling the method at the receiving HOPS, the HOPS shall commence recording the Seq# values in Data Frames received from the transmitting HOPS, and checking for missing Data Frames shall commence.

#### **6.2.2.9 Action taken upon receipt of a Data Frame Not Received Advisory (0913) Message**

When a HOPS receives a Data Frame Not Received Advisory message from another HOPS then it shall:

- If possible, the recipient of this message resends the original Data Frame with the original sequence number (Seq#); or
- If a new or replacement Data Frame must be created, it sends that Data Frame with a new sequence number, and also sends the Response to a Data Frame Not Received Advisory message advising the other party of the replacement sequence numbers;
- If it is not possible to resend the Data Frame then the Response to a Data Frame Not Received Advisory message shall be sent with ResponseCode set to 3;
- If the Data Frame has been ACKed or NAKed by the recipient, then the Response to a Data Frame Not Received Advisory message shall be sent with ResponseCode set to 4.

#### **6.2.3 ITSO Security Management Service (ISMS)**

The AMS function within a HOPS is required to interface to the central ISMS system via VPN over the public Internet, using XML formatted files. The Message Processor shall handle this communication as defined in the following clauses.

##### **6.2.3.1 Message format and transmission method**

All HOPS shall support the generation and transmission of messages to the ISMS in the ITSO transmission format defined in ITSO TS 1000-9.

All HOPS shall support the receiving and processing of messages from the ISMS in the ITSO transmission format defined in ITSO TS 1000-9.

All HOPS shall support the generation and transmission of XML tagged message files as defined in ITSO TS 1000-9.

All HOPS shall support the receiving and processing of XML tagged message files as defined in ITSO TS 1000-9.

All HOPS shall provide support for transmission and receipt of message files via a VPN as defined in ITSO TS 1000-9.

### 6.2.3.2 Message set

The Message Handler shall support the following message set from ISMS to HOPS:

• Transfer of ISAM Security Files	Class 3
• Transfer of ISMS-AMS Information Packet	Class 2

The Message Handler shall support the following message set from HOPS to ISMS:

• Transfer of ISMS Security Requests	Class 3
• Transfer of ISMS Information Request	Class 2
• Transfer of ISAM Security Acknowledgements	Class 3

See ITSO TS 1000-9 for details of the different message classes.

See ITSO TS 1000-8 for a detailed list of the messages and their message codes.

### 6.2.3.3 Message security

The Message Processor shall verify the authenticity and integrity of all received messages from the ISMS in the manner defined in ITSO TS 1000-9.

The Message Processor shall verify the authenticity and integrity of all received Secure Data Frames from the ISMS in the manner defined in ITSO TS 1000-9. It shall use the services of the HSAM to carry out said verification.

The Message Processor shall seal all Secure Data Frames sent to the ISMS in the manner defined in ITSO TS 1000-9. It shall use the services of the HSAM to carry out said sealing.

The Message Processor shall store a copy of each and every received message from the ISMS in the Message Store prior to any processing of said message.

The Message Processor shall store a copy of each and every transmitted message to the ISMS in the Message Store.

### 6.2.3.4 Positive acknowledgements and routing

The Message Processor shall generate the required positive acknowledgements to received messages / Data Frames from the ISMS. See ITSO TS 1000-9 for details of the positive acknowledgement process.

The Message Processor shall re-transmit messages to the ISMS when a valid ACK is not received within the required period as defined in ITSO TS 1000-9.

The Message Processor shall route (forward on) messages received from the ISMS that it is not authorised to process. Said routing shall be in the manner defined in ITSO TS 1000-9.

## 6.3 Internal client components

### 6.3.1 Accounts

#### 6.3.1.1 Message Processor to Accounts

The Message Processor shall transfer relevant received and verified 'on-us' data to the following Accounts sub-systems:

- ITSO Shell Accounts
- Product Accounts

Verified 'on-us' data will result from reception (by the Message Processor) of the following message types from POSTs and/or HOPS:

- Class 1 Transaction Record Data Messages
- Class 2 Envelop Frames
- Class 2 Data Correction Records
- Class 2 Queries

Class 1 Transaction Records will usually be the main source of this data, originating from POSTs which are 'directly under' the HOPS in question.

Class 2 Envelop Frames will be the source of data when the data from the POST has had to be routed via another HOPS (i.e. the HOPS in question is not the 'first-line' HOPS for the POST). In effect the intermediate HOPS has treated said data as a 'not-on-us' transaction.

Class 2 Data Correction Records are used to allow corrections to stored entities by external parties.

Class 2 Queries do not provide data that is stored by the Account sub-systems, but acts as a request for already stored data.

#### 6.3.1.2 Accounts to Message Processor

The Message Processor shall accept, seal and transmit out data from the following Accounts sub-systems:

- ITSO Shell Accounts
- Product Accounts
- List Processing

The Message Processor shall generate one or more of the following message types to POSTs and/or HOPS as a result:

- Class 2 Configuration Data Lists
- Class 2 Query Responses

Class 2 Configuration Data Lists are sent to POSTs by the HOPS. The current configuration lists are: Hotlist; Actionlist.

Class 2 Query Responses contain the data requested by a Query message previously received.

### 6.3.2 Services

The Message Processor shall provide the required information to the Services component such that said component can carry out its required tasks.

The Message Processor shall monitor and record relevant Quality of Service metrics relating to its internal tasks, and shall make these available to the Services component as required.

### 6.3.3 AMS

#### 6.3.3.1 Message Processor to AMS

The Message Processor shall transfer relevant received and verified 'on-us' data to the AMS component. This data will result from reception (by the Message Processor) of the following message types from POSTs, HOPS and the ISMS:

- Class 2 ISMS-AMS Information Packet
- Class 3 ISAM Security Acknowledgements
- Class 3 ISAM Security Files from the ISMS

Class 2 ISMS-AMS Information Packets are originated by the ISMS and are used to provide informative data to the AMS.

Class 3 ISAM Security Acknowledgements are originated by an ISAM (in a managed POST) or an HSAM (in a managed HOPS) in response to a Security File.

Class 3 ISAM Security Files are originated by the ISMS at the request of the AMS for inclusion in an AMS message destined for a target ISAM or HSAM.

Note: ISAM Security Files sent by the ISMS to the local HSAM shall be directly applied to the local HSAM along with any other necessary AMS generated Security Files.

#### 6.3.3.2 AMS to Message Processor

The Message Processor shall accept, seal and transmit out data from the AMS component. The Message Processor shall generate one or more of the following message types to as a result:

- Class 2 Parameter Tables
- Class 2 ISMS Information Request
- Class 3 ISMS Security Requests
- Class 3 ISAM Security Files
- Class 3 ISAM Security Acknowledgements

Class 2 Parameter Tables are sent from the AMS to managed POSTs. These tables make up the POST configuration data.

Class 2 ISMS Information Requests are sent from the AMS to the ISMS to request data that is not security related.

Class 2 ISMS Security Requests are sent from the AMS to the ISMS to request security related data.

Class 3 ISAM Security files are sent from the AMS to ISAMs in managed POSTs and HOPS to configure locally controlled tables. As part of this process any Security Files originated by the ISMS shall be re-packaged by the AMS into a class 3 message that contains, in the correct order for application to the target ISAM or HSAM, all the Secure Data Frames need to complete a single self-contained update to the target. The class 3 message Originator shall be the AMS.

Note: To fulfil the above requirement, Secure Data Frames sourced by AMS are likely to be interleaved with Secure Data Frames sourced by the ISMS. The first Secure Data Frame in the message shall be the first to be applied to the ISAM followed by the next etc.... until the Last frame in the message has been applied.

Class 3 ISAM Security Acknowledgements received from a POST or HOPS in a single message may contain acknowledgements destined for the AMS or the ISMS or Both. These shall be filtered by the AMS process and those intended for the AMS processed directly by the AMS. Those intended for ISMS may be inspected as required by an AMS process and shall then be repackaged into a single Class 3 message for forwarding to the ISMS. In this case the class 3 message originator shall be the AMS.

Note: It is recommended that the digital signature of any ISMS Security Acknowledgements inspected by the AMS is verified prior to using any of its contents.

#### **6.3.3.3 AMS - HSAM data transfer**

Data transfer between the AMS and the local HSAM shall take place via the Message Processor.

### **6.4 Internal resource components**

#### **6.4.1 HSAM**

The Message Processor shall use the services of the local HSAM to:

- Seal Data Frames
- Seal Secure Data Frames
- Verify the Seal on Data Frames
- Generate the IBatch Header delete parameters for Transaction Session Batch management

#### **6.4.2 Message Store**

The Message Processor shall store a copy of each and every incoming message in the Message Store prior to any processing. Each stored message shall be timestamped with its reception time and date.

The Message Processor shall store a copy of each and every transmitted message in the Message Store. Each stored message shall be timestamped with its transmission time and date.

## 7. ITSO Shell Accounts (ISA) and ITSO Product Accounts (IPA)

This clause defines requirements for the following:

- ITSO Shell Accounts (ISA) which relate to ITSO Shells
- ITSO Product Accounts (IPA) which relate to ITSO Product Entities (IPE) instances
- Account processing
- List processing facilities
  - Hotlists
  - Actionlists

Provision of the facilities defined in this clause is optional in a HOPS instance. It should be noted that only those facilities defined in this clause relevant to a HOPS instance need be provided in that instance.

Each ITSO Compliant Scheme shall include at least one HOPS capable of providing the account management functions defined in this clause.

The account definitions herein are based on the ITSO Transaction Record messages defined in ITSO TS 1000-6. Each data element within an account shall be formatted such that the full value range of any matching parameter in a Transaction Record message may be stored in the account.

### 7.1 Account Types

The HOPS shall keep each account as a logical copy of the corresponding data in the ITSO Shell or IPE instance as appropriate, together with any other relevant data.

There is no direct link between products (IPE instances) and ITSO Shells. There is however a link between Actors: the Product Owners and ITSO Shell Owners.

### 7.2 The ITSO Shell Account (ISA)

#### 7.2.1 General

The ITSO Shell Owner shall maintain an ISA for each ITSO Shell issued by them.

The ISA shall store information about the ITSO Shell.

In the instance where a Customer Media is issued containing a single product in a Compact Shell<sup>7</sup>, creation of an ISA is optional.

#### 7.2.2 Data requirements

An ISA shall comprise the following data elements, and may additionally contain additional data elements at the discretion of the HOPS owner:

- The entire data set returned in Transaction Records relating to ITSO Shell creation, message code 0001, and stored as individual data elements
- The entire data set returned in Transaction Records relating to ITSO Shell amendment, message code 0002, and stored as individual data elements
- The entire data set returned in Transaction Records relating to acceptance of a deposit for the ITSO Shell, message code 0302, and stored as individual data elements

---

<sup>7</sup> Refer to ITSO TS 1000-2 for a definition of Compact Shells

- Status, which shall be used to record the status of the ITSO Shell, where the following status conditions shall be recorded:
  - ITSO Shell Issued but not activated
  - ITSO Shell Issued and activated
  - ITSO Shell dormant
  - ITSO Shell Hotlisted
  - ITSO Shell Blocked
  - ITSO Shell deleted from host Customer Media
  - Host Customer Media unavailable (i.e. the host Customer Media has been destroyed<sup>8</sup>, Blocked or otherwise disabled)
- HotlistStatus, which shall be used to record the Hotlist status of the ITSO Shell, where the following status conditions shall be recorded
  - Not Hotlisted
  - Lost
  - Stolen
  - ITSO Shell Holder Rule Breach (the CM holder has breached one of the Shell Owners rules)
  - ITSO Shell Owner Rule Breach (the Shell Owner has withdrawn the Shell for administrative reasons)
  - Security Rule Breach (the Shell Owner has Hotlisted the Shell because a security rule has been breached)
- HotlistAction, which shall be used to record the action to take recorded in a Hotlist item associated with this ITSO Shell, as defined in ITSO TS 1000-6
- Customer Media Disposition, which shall be used to record the Customer Media disposition instruction contained in a Hotlist item associated with this ITSO Shell, as defined in ITSO TS 1000-6
- Cross Reference to ISA History Data Store

The Status and HotlistStatus elements shall be updated either upon receipt of the appropriate data message from a POST, or upon operation of a manually operated control indicating a change in status.

### 7.2.3 ISA History Data Store

Associated with the ITSO Shell ISA shall be an ISA History Data Store. This store shall contain summary details of each IPE written to that ITSO Shell.

An ISA History Data Store shall comprise of the following data elements:

- Cross reference to the ISA
- The entire data set returned in Transaction Records relating to creation, amendment and deletion of IPE instances, message codes 0005, 0006, 0007, 0008, 0009, and stored as individual data elements
- Status which shall be used to record the status of the IPE instance, where the following status conditions shall be recorded
  - IPE instance created
  - IPE instance expired (but not deleted)
  - IPE instance Blocked, and

---

<sup>8</sup> It is recommended that the destruction process should be an auditable process

- IPE instance deleted from ITSO Shell

#### 7.2.4 Managing the ITSO Shell Account (ISA)

The HOPS shall maintain the ISA ensuring that all Transaction Records relating to the ITSO Shell shall be used to promptly update ISA data elements as appropriate.

The HOPS shall maintain the ISA History Data Store by promptly adding to it or updating it as appropriate upon receipt of Transaction Records from POSTs.

### 7.3 ITSO Product Accounts (IPA)

The HOPS shall create and maintain IPAs for all IPE instances issued under the authority of and controlled by the Product Owner HOPS.

The HOPS shall promptly create, add to or update IPAs upon receipt of Transaction Records from POSTs.

Only relevant Product Account types need be implemented in an ITSO Compliant Scheme, i.e., only Product Account types which will be used by the HOPS Owner need be implemented.

In some circumstances, there may be more than one status condition which could be stored in the Status data element. The IPA status data element shall be implemented in such a way that it shall be possible to record one, several or all status conditions at the same time.

#### 7.3.1 Stored Travel Rights (STR) IPA; relating to IPE TYP 2

The STR IPA shall comprise the following data elements, and may additionally contain additional data elements at the discretion of the HOPS owner:

- The entire data set returned in Transaction Records relating to TYP 2 IPE instance creation, message code 0120, and stored as individual data elements
- Status, which shall be used to record the status of the IPE instance, where the following status conditions shall be recorded
  - IPE instance Issued but not activated
  - IPE instance Issued and activated
  - IPE instance MaxAmount exceeded
  - IPE instance Value is zero
  - IPE instance Value is negative
  - IPE instance dormant
  - IPE instance Hotlisted
  - IPE instance Blocked
  - IPE instance deleted from the ITSO Shell
  - Host unavailable (i.e. the host Customer Media has been destroyed, Hotlisted or otherwise disabled)
- HotlistStatus, which shall be used to record the Hotlist status of the IPE Instance, where the following status conditions shall be recorded
  - Not Hotlisted
  - Lost
  - Stolen
  - IPE instance Holder Rule Breach (the CM holder has breached one of the IPE Owners rules)
  - IPE instance Owner Rule Breach (the IPE Owner has withdrawn the IPE for administrative reasons)



- Security Rule Breach (the IPE Owner has Hotlisted the IPE because a security rule has been breached)
- HotlistAction, which shall be used to record the action to take recorded in a Hotlist item associated with this ITSO Shell, as defined in ITSO TS 1000-6
- Customer Media Disposition, which shall be used to record the Customer Media disposition instruction contained in a Hotlist item associated with this ITSO Shell, as defined in ITSO TS 1000-6
- IPE instance Holder information where the STR IPE instance owner is not also the ITSO ID IPE instance owner
- IPE instance Holders bank or credit card details where appropriate
- Cross reference to a History Data Store

The History Data Store shall contain a record of all transactions conducted with the STR IPE instance, and shall be updated promptly upon receipt of transaction records from POSTs. The History Data Store shall comprise of all the data elements defined in the TYP 2 Value Record Group as defined in ITSO TS 1000-5, together with details of any other changes, the location at which the changes were conducted and the operator responsible for the changes.

Upon receipt of a 0103 Load Check transaction record, the HOPS shall check whether a record of this Transaction has already been stored in the IPA. If a record has already been stored then the 0103 message shall be discarded and no further action taken. If a record has not been stored then the HOPS shall update the relevant IPA, make a record in the IPA history store using the information contained in the 0103 message, and the event shall be logged for the attention of the system operator. If subsequently a 0101 or 0102 message relating to the same Transaction is received, this shall be used to update the IPA with those data elements not contained in the 0103 message, and a new IPA history record shall not be created. When an 0101 or an 0102 message is received the HOPS shall, before processing it, check whether an 0103 message relating to the same transaction has already been received and processed.

The Status and HotlistStatus elements shall be updated either upon receipt of the appropriate data message from a POST, or upon operation of a manually operated control indicating a change in status.

### 7.3.2 Charge To Account (CTA) IPA; relating to IPE TYPs 4 and 5

Two forms of CTA IPA shall be provided, reflecting the differences between TYP 4 and TYP 5 IPE's.

The CTA IPA shall comprise the following data elements, and may additionally contain additional data elements at the discretion of the HOPS owner:

- The entire data set returned in Transaction Records relating to TYP 4 IPE instance creation or TYP 5 IPE instance creation, message codes 0122 and 0124, and stored as individual data elements
- Status, which shall be used to record the status of the IPE instance, where the following status conditions shall be recorded
  - IPE instance Issued but not activated
  - IPE instance Issued and activated
  - IPE instance MaxAmount exceeded
  - IPE instance dormant
  - IPE instance Hotlisted
  - IPE instance Blocked
  - IPE instance deleted from the ITSO Shell
  - Host unavailable (i.e. the host Customer Media has been destroyed, Hotlisted or otherwise disabled)
- HotlistStatus, which shall be used to record the Hotlist status of the IPE Instance, where the following status conditions shall be recorded
  - Not Hotlisted
  - Lost

- Stolen
- IPE instance Holder Rule Breach (the CM holder has breached one of the IPE Owners rules)
- IPE instance Owner Rule Breach (the IPE Owner has withdrawn the IPE for administrative reasons)
- Security Rule Breach (the IPE Owner has Hotlisted the IPE because a security rule has been breached)
- HotlistAction, which shall be used to record the action to take recorded in a Hotlist item associated with this ITSO Shell, as defined in ITSO TS 1000-6
- Customer Media Disposition, which shall be used to record the Customer Media disposition instruction contained in a Hotlist item associated with this ITSO Shell, as defined in ITSO TS 1000-6
- IPE instance Holder information where the CTA IPE instance owner is not also the ITSO ID IPE instance owner
- IPE instance Holders bank or credit card details
- Normal refresh location<sup>9</sup>
- Cross reference to a History Data Store

The History Data Store shall contain a record of all transactions conducted with the associated CTA IPE instance, and shall be updated promptly upon receipt of transaction records from POSTs. The History Data Store shall comprise of all the data elements defined in the TYP 4 Value Record Group or the TYP 5 Value Record Group as defined in ITSO TS 1000-5, together with details of any other changes, the location at which the changes were conducted and the operator responsible for the changes.

The Status and HotlistStatus elements shall be updated either upon receipt of the appropriate data message from a POST, or upon operation of a manually operated control indicating a change in status.

### 7.3.3 Loyalty IPA, relating to IPE TYPs 3 and 17

The loyalty IPA shall comprise the following data elements, and may additionally contain additional data elements at the discretion of the HOPS owner:

- The entire data set returned in Transaction Records relating to IPE instance creation, message codes 020B or 0206, and stored as individual data elements
- The entire data set returned in Transaction Records relating to IPE instance use, message codes 0203, 0204 or 0205, and stored as individual data elements
- Status, which shall be used to record the status of the IPE instance, where the following status conditions shall be recorded
  - IPE instance Issued but not activated
  - IPE instance Issued and activated
  - IPE instance MaxAmount exceeded
  - IPE instance dormant
  - IPE instance Hotlisted
  - IPE instance Blocked
  - IPE instance deleted from the ITSO Shell
  - Host unavailable (i.e. the host Customer Media has been destroyed, Hotlisted or otherwise disabled)

---

<sup>9</sup> A location at which the IPE user normally presents the card in order for an Actionlist item to be actioned by means of which the IPE's MaximumAmount data element is reset to reflect a payment made by the IPE user to settle the account

- HotlistStatus, which shall be used to record the Hotlist status of the IPE Instance, where the following status conditions shall be recorded
  - Not Hotlisted
  - Lost
  - Stolen
  - IPE instance Holder Rule Breach (the CM holder has breached one of the IPE Owners rules)
  - IPE instance Owner Rule Breach (the IPE Owner has withdrawn the IPE for administrative reasons)
  - Security Rule Breach (the IPE Owner has Hotlisted the IPE because a security rule has been breached)
- HotlistAction, which shall be used to record the action to take recorded in a Hotlist item associated with this ITSO Shell, as defined in ITSO TS 1000-6
- Customer Media Disposition, which shall be used to record the Customer Media disposition instruction contained in a Hotlist item associated with this ITSO Shell, as defined in ITSO TS 1000-6
- IPE instance Holder information where the IPE instance owner is not also the ITSO ID IPE instance owner
- Cross reference to a History Data Store

The History Data Store shall contain a record of all transactions conducted with the associated Loyalty IPE instance, and shall be updated promptly upon receipt of transaction records from POSTs.

Where the IPA relates to a TYP 3 IPE instance, the History Data Store shall comprise of all the data elements defined in the TYP 3 Value Record Group as defined in ITSO TS 1000-5, together with details of any other changes, the location at which the changes were conducted and the operator responsible for the changes.

Where the IPA relates to a TYP 17 IPE instance, the History Data Store shall comprise the date and time of the transaction; number of loyalty points, and any other information that the IPE instance owner wishes to store, together with details of any other changes, the location at which the changes were conducted and the operator responsible for the changes.

The Status and HotlistStatus elements shall be updated either upon receipt of the appropriate data message from a POST, or upon operation of a manually operated control indicating a change in status.

### 7.3.4 ITSO ID IPA

The IPA shall comprise the following data elements, and may additionally contain additional data elements at the discretion of the HOPS owner:

- The following data elements returned in Transaction Records relating to IPE instance creation, message code 0200, and stored as individual data elements
  - StandardData (stored as individual data elements)
  - Amount
  - AmountCurrencyCode
  - HolderTitle
  - HolderSurname
  - HolderOtherNames
  - HolderAddress1
  - HolderAddress2
  - HolderAddress3
  - HolderAddress4
  - HolderPostcode
  - HolderPhoneDay

- HolderPhoneHome
- HolderPhoneMobile
- HolderEmail
- IPELength
- IPEBitMap
- IPEFormatRevision
- RemoveDate
- ProductRetailer
- IDFlags
- PassbackTime
- DateOfBirth
- Language
- HolderID
- DepositMethodOfPayment
- DepositVATSalesTax
- DepositCurrencyCode
- DepositAmount
- Status, which shall be used to record the status of the IPE instance, where the following status conditions shall be recorded
  - IPE instance Issued but not activated
  - IPE instance Issued and activated
  - IPE instance MaxAmount exceeded
  - IPE instance dormant
  - IPE instance Hotlisted
  - IPE instance Blocked
  - IPE instance deleted from the ITSO Shell
  - Host unavailable (i.e. the host Customer Media has been destroyed, Hotlisted or otherwise disabled)
- HotlistStatus, which shall be used to record the Hotlist status of the IPE Instance, where the following status conditions shall be recorded
  - Not Hotlisted
  - Lost
  - Stolen
  - IPE instance Holder Rule Breach (the CM holder has breached one of the IPE Owners rules)
  - IPE instance Owner Rule Breach (the IPE Owner has withdrawn the IPE for administrative reasons)
  - Security Rule Breach (the IPE Owner has Hotlisted the IPE because a security rule has been breached)
- HotlistAction, which shall be used to record the action to take recorded in a Hotlist item associated with this ITSO Shell, as defined in ITSO TS 1000-6
- Customer Media Disposition, which shall be used to record the Customer Media disposition instruction contained in a Hotlist item associated with this ITSO Shell, as defined in ITSO TS 1000-6
- IPE instance Holder information where the IPE instance owner is not also the ITSO ID IPE instance owner
- Cross reference to a History Data Store

The History Data Store shall provide a trail of all changes to the IPE instance and IPA, including the date & time of said changes, the nature of said changes and the location and operator ID responsible for the change.

The History Data Store shall contain a record of all transactions conducted with the associated ITSO ID IPE instance, and shall be updated promptly upon receipt of transaction records from POSTs.

The Status and HotlistStatus elements shall be updated either upon receipt of the appropriate data message from a POST, or upon operation of a manually operated control indicating a change in status.

### 7.3.5 Entitlement IPA

The IPA shall comprise the following data elements, and may additionally contain additional data elements at the discretion of the HOPS owner:

- The following data elements returned in Transaction Records relating to IPE instance creation, message code 0200, and stored as individual data elements;
  - StandardData – stored as individual data elements
  - Amount
  - AmountCurrencyCode
  - HolderTitle
  - HolderSurname
  - HolderOtherNames
  - HolderAddress1
  - HolderAddress2
  - HolderAddress3
  - HolderAddress4
  - HolderPostcode
  - HolderPhoneDay
  - HolderPhoneHome
  - HolderPhoneMobile
  - HolderEmail
  - IPE-TYP
  - IPELength
  - IPEBitMap
  - IPEFormatRevision
  - RemoveDate
  - ProductRetailer
  - CPICC
  - IDFlags
  - PassbackTime
  - DateOfBirth
  - Language
  - HolderID
  - RoundingFlag
  - RoundingValueFlag

- EntitlementExpiryDate
- DepositMethodOfPayment
- DepositVATSalesTax
- DepositCurrencyCode
- DepositAmount
- ConcessionaryClass
- Status, which shall be used to record the status of the IPE instance, where the following status conditions shall be recorded:
  - IPE instance Issued but not activated
  - IPE instance Issued and activated
  - IPE instance MaxAmount exceeded
  - IPE instance dormant
  - IPE instance Hotlisted
  - IPE instance Blocked
  - IPE instance deleted from the ITSO Shell
  - Host unavailable (i.e. the host Customer Media has been destroyed, Hotlisted or otherwise disabled)
- HotlistStatus, which shall be used to record the Hotlist status of the IPE Instance, where the following status conditions shall be recorded:
  - Not Hotlisted
  - Lost
  - Stolen
  - IPE instance Holder Rule Breach (the CM holder has breached one of the IPE Owners rules)
  - IPE instance Owner Rule Breach (the IPE Owner has withdrawn the IPE for administrative reasons)
  - Security Rule Breach (the IPE Owner has Hotlisted the IPE because a security rule has been breached)
- HotlistAction, which shall be used to record the action to take recorded in a Hotlist item associated with this ITSO Shell, as defined in ITSO TS 1000-6;
- Customer Media Disposition, which shall be used to record the Customer Media disposition instruction contained in a Hotlist item associated with this ITSO Shell, as defined in ITSO TS 1000-6;
- IPE instance Holder information where the IPE instance owner is not also the ITSO ID IPE instance owner;
- Cross reference to a History Data Store.

The History Data Store shall provide a trail of all changes to the IPE instance and IPA, including the date & time of said changes, the nature of said changes and the location and operator ID responsible for the change.

The Status and HotlistStatus elements shall be updated either upon receipt of the appropriate data message from a POST, or upon operation of a manually operated control indicating a change in status.

### 7.3.6 Ticket and Similar Product IPAs

This IPA shall be used to store details of ticketing and other similar products created using IPE's, where creation of such IPE instances is reported using code 207 messages. It should be noted that the data set returned in the code 0207 messages will vary according to the IPE TYP created

The IPA shall comprise the following data elements, and may additionally contain additional data elements at the discretion of the HOPS owner:

- The entire data set returned in Transaction Records relating to IPE instance creation, message code 0207, and stored as individual data elements
- Status, which shall be used to record the status of the IPE instance, where the following status conditions shall be recorded
  - IPE instance Issued but not activated
  - IPE instance Issued and activated
  - IPE instance MaxAmount exceeded
  - IPE instance dormant
  - IPE instance Hotlisted
  - IPE instance Blocked
  - IPE instance deleted from the ITSO Shell
  - Host unavailable (i.e. the host Customer Media has been destroyed, Hotlisted or otherwise disabled)
- HotlistStatus, which shall be used to record the Hotlist status of the IPE Instance, where the following status conditions shall be recorded
  - Not Hotlisted
  - Lost
  - Stolen
  - IPE instance Holder Rule Breach (the CM holder has breached one of the IPE Owners rules)
  - IPE instance Owner Rule Breach (the IPE Owner has withdrawn the IPE for administrative reasons)
  - Security Rule Breach (the IPE Owner has Hotlisted the IPE because a security rule has been breached)
- HotlistAction, which shall be used to record the action to take, recorded in a Hotlist item associated with this ITSO Shell, as defined in ITSO TS 1000-6
- Customer Media Disposition, which shall be used to record the Customer Media disposition instruction contained in a Hotlist item associated with this ITSO Shell, as defined in ITSO TS 1000-6
- IPE instance Holder information where the IPE instance owner is not also the ITSO ID IPE instance owner.
- IPE instance Holders bank or credit card details
- Normal refresh location<sup>10</sup>
- Cross reference to a History Data Store

The History Data Store shall contain a record of all transactions conducted with the associated IPE instance, and shall be updated promptly upon receipt of transaction records from POSTs. The History Data Store shall comprise of all the data elements defined in the relevant Value Record Group as defined in ITSO TS 1000-5, together with details of any other changes, the location at which the changes were conducted and the operator responsible for the changes.

The Status and HotlistStatus elements shall be updated either upon receipt of the appropriate data message from a POST, or upon operation of a manually operated control indicating a change in status.

---

<sup>10</sup> A location at which the IPE user normally presents the card in order for an Actionlist item to be actioned by means of which the IPE's MaximumAmount data element is reset to reflect a payment made by the IPE user to settle the account

## 7.4 Account Processing

### 7.4.1 User access to accounts

The HOPS shall provide user access to accounts and the list processing facility subject to the data access permissions configured for each user.

### 7.4.2 General Account processing

The HOPS shall receive transaction record messages pertaining to the creation, deletion, Hotlisting, modification, and usage of IPE instances, and shall use the data elements in said messages to promptly update related IPAs, the IPA history store, and the ITSO Shell ISA where required.

The HOPS shall maintain ISAs until after the archive action following either:

- the ITSO Shell ExpiryDate or
- the CM in which the Shell resides has been destroyed<sup>11</sup>, and the ISA status has been marked to reflect this or
- the Shell has been deleted from the CM, and the ISA status has been updated to reflect this

The HOPS shall maintain IPAs until after the archive action following either:

- a date defined as (IPE ExpiryDate plus IPE RemoveDate) or
- the CM in which the Shell containing the IPE associated with this IPA resides has been destroyed<sup>12</sup>, and the ISA and IPA status' has been marked to reflect this or
- the Shell containing the IPE associated with this IPA has been deleted from the CM, and the ISA and IPA status' has been updated to reflect this

It is not mandatory that ISAs and IPAs be deleted when the defined triggers occur. A HOPS may maintain the accounts for longer periods if the operator so desires.

### 7.4.4 STR Auto-Top-Up operation

Stored Travel Rights may be automatically topped up by a predetermined amount when the value of STR falls to a predetermined level.

The HOPS shall include a facility to initiate, modify or cease Auto-Top-Up for STR IPE instances, and shall generate Actionlist messages to do that, as defined in ITSO TS 1000-6.

The HOPS shall, on receipt of an Auto-Top-Up Transaction Record from a POST, update the Stored Travel Rights IPA to reflect the new IPE instance contents<sup>13</sup>.

### 7.4.5 STR Actionlist top up

Stored Travel Rights may be added through an Actionlist transaction. The HOPS shall include a facility to control, instigate and record use of this feature.

---

<sup>11</sup> It is recommended that the destruction process should be an auditable process

<sup>12</sup> It is recommended that the destruction process should be an auditable process

<sup>13</sup> A payment collection cycle should also be instigated by this event



#### 7.4.6 STR scheme exposure

In order to limit exposure, the maximum amount of Stored Travel Rights that are allowed to be held within a Stored Travel rights IPE instance is specified within the IPE instance. This is the maximum value that can be held on a Stored Travel Rights IPE instance, and any STR top up request which would cause this value to be exceeded shall fail<sup>14</sup>.

The HOPS shall monitor Transaction Records received, and shall highlight error conditions to the STR scheme operator, including but not limited to instances where a STR IPE instance is used for payment, but where no add value Transaction Record is received.

#### 7.4.7 STR Negative Balance

These specifications allow the amount of Stored Travel Rights held within an IPE instance to be negative, subject to IPE element MaximumNegativeAmount. The HOPS shall provide a facility to control and record the use of this feature.

#### 7.4.8 Handling STR Add-Value Records

The HOPS shall from time to time receive duplicate add-value transactions from POSTs. This is a POST function described in ITSO TS 1000-3.

The HOPS shall check whether or not the add-value transaction record has already been received and:

- if the record has been previously received, the record shall be discarded
- if the record has not been previously received, then it shall be processed in the normal way

#### 7.4.9 CTA IPA processing

A facility shall be provided for the control and recording of use of CTA IPE instances.

#### 7.4.10 Auto-Renew

Some IPE types have an Auto-Renew facility, whereby the IPE instance validity can be automatically extended, as defined in ITSO TS 1000-5.

The HOPS shall provide facilities to control and record the use of Auto-Renew features, and specifically to:

- enable or disable Auto-Renew within an IPE instance
- Set Auto-Renew parameters
- Record instances of Auto-Renew events<sup>15</sup>

### 7.5. List Processing

This clause describes how the HOPS shall generate and transmit Hotlists and Actionlists.

The HOPS shall provide a facility enabling:

- Generation of Hotlists and Actionlists

---

<sup>14</sup> The ISAM also includes aggregate limits. See the AMS section of this document, ITSO TS 1000-3 and ITSO TS 1000-7

<sup>15</sup> A payment collection cycle should also be instigated by this event

- Detection that Hotlist and Actionlist items have been fulfilled, by means of processing Transaction Records returned by the POST actioning the list item
- Transmission of said Hotlists and Actionlists to POSTS, where the AMS shall be used to identify individual POSTs, all POSTs controlled by the AMS, or ranges of POSTs
- Transmission of said Hotlists and Actionlists to other HOPS for inclusion on their local lists
- Receiving of Hotlists and Actionlists from other HOPS, and for incorporating items from these lists into local lists for onward distribution to POSTs. Local list content shall be governed by the ITSO Business Rules
- Forwarding of Transaction Records relating to fulfilment of Hotlist and Actionlist items generated by other HOPS to those HOPS

### 7.5.1 Creating Lists

The list format, structure and content are defined in ITSO TS 1000-6. Each list consists of separate items.

The nature of the item structure used shall depend upon whether the target Customer Media contains an ITSO Shell and IPE instance's, or contains just a low memory IPE instance, and also whether the ITSO Shell contains an ISRN.

If the Customer Media contains an ITSO Shell, and the ISRN is known, then:

- a key type 0 header shall be used
- if an IPE instance is the item's target, the optional IPE identity data group shall be used

If the Customer Media does not contain an ITSO Shell or ISRN; then:

- a key type 1 header shall be used

Hotlists and Actionlists shall be stored within POST memory and the list shall be transmitted to the POST using a class 2 message.

### 7.5.2 Hotlists

The HOPS shall provide a function to initiate a Hotlist action on either:

- A specific ITSO Shell
- A specific IPE instance

#### 7.5.2.1 Identification of Hotlists

Each Hotlist shall be identified by a HotListIdentifier, generated by the originating HOPS.

All Hotlist items in a list shall contain the same HotListIdentifier value.

A POST shall use a HotListIdentifier when processing a received list as defined in ITSO TS 1000-3.

A HOPS shall use a HotListIdentifier when processing a received list as follows:

1. If the received HotListIdentifier equals the current HotListIdentifier: append the received list to the current list;
2. If the received HotListIdentifier is greater than the current HotListIdentifier taking into account rollover as defined in ITSO TS 1000-1) AND RecordType=1 or 3: delete the current list and replace with the new list.
3. In all other cases do not delete or append to the current list, but send an 0400 Exception message to the HOPS with ExceptionType set to a value of 148 as defined in ITSO TS 1000-6.

HOPS shall support a mix of POST types, where some support RecordTypes three (3) and five (5), and where others only support RecordType one (1), whilst still taking advantage of the enhanced operation provided by RecordTypes three (3) and five (5) with those POSTs that support this functionality.

### 7.5.2.2 Un-Block by Actionlist

The HOPS shall provide a facility to unblock ITSO Shells and IPEs by means of an Actionlist item.

Clearly it is possible for an ITSO Shell or IPE instance, previously blocked by Hotlisting, and subsequently unblocked, to be blocked again if the Customer Media is presented to a POST containing the original Hotlist. This is prevented by means of the ITSO Shell and IPE iteration numbers, INS# and INP#. These values are included in the Hotlist search criteria, and only if the values in the list match the values in the ITSO Shell or IPE instance will the Hotlist item be actioned.

When a POST actions an unblock item, it increments the value of INS# or INP# as appropriate, and returns the new value in the event Transaction Record.

The new value received from the POST shall be stored in the ISA or IPA as appropriate, and used in any subsequent Hotlist items generated.

### 7.5.2.3 Handling Hotlist Action Event Transaction Records.

The HOPS shall process Hotlist action event Transaction Records received, and shall promptly update the appropriate ISA or IPA.

## 7.5.3 Actionlists

The HOPS shall provide a function to initiate an Actionlist action on either:

- A specific ITSO Shell
- A Specific IPE instance

### 7.5.3.1 Identification of Actionlists

Each Actionlist shall be identified by an ActionListIdentifier, generated by the originating HOPS.

All Actionlist items in a list shall contain the same ActionListIdentifier value.

Note that a POST shall use ActionListIdentifier when processing a received list as defined in ITSO TS 1000-3.

A HOPS shall use ActionListIdentifier when processing a received list as follows:

1. If the received ActionListIdentifier equals the current ActionListIdentifier AND RecordType = 2 OR 6, append the received list to the current list;
2. If the received ActionListIdentifier is greater than the current ActionListIdentifier, taking into account rollover as defined in ITSO TS 1000-1 AND RecordType = 2 OR 4, delete the current list and replace with the new list;
3. In all other cases do not delete or append to the current list, but send an 0400 Exception message to the HOPS with ExceptionType set to a value of 148 as defined in ITSO TS 1000-6.

HOPS shall support a mix of POST types, where some support RecordTypes four (4) and six (6), and where others only support RecordType two (2), whilst still taking advantage of the enhanced operation provided by RecordTypes four (4) and six (6) with those POSTs that support this functionality.

### 7.5.3.2 Prevention of duplicate actioning

In many cases, it is imperative that an Actionlist item does not execute more than once.

To ensure that an Actionlist item is not processed more than once, and that action items are actioned in the correct sequence, the ActionSequenceNumber IPE data element is provided.

Only one Actionlist item shall exist for a given instance of an IPE at any one time. A match event shall have been received and applied to the relevant IPE account in the HOPS before the next Actionlist item for the IPE instance is

generated. If an Actionlist item (acting on an IPE instance) is not actioned for any reason then subsequent actions (acting on the same instance) cannot take place.

In this context an Actionlist item which creates or deletes an IPE shall be considered an action on the Shell, and is not restricted in the same way as an action on an IPE instance, excepting that actions of Action to Take codes one (1) and six (6) shall be limited to one per Shell at any given time so as to minimise risk.

For an Actionlist item acting on ITSO Shells, or acting on an IPE which does not contain a Value Group, then ActionSequenceNumber has no meaning because the ITSO Shell or IPE without a Value Group does not contain an ActionSequenceNumber. In these circumstances, the HOPS shall set the ActionSequenceNumber in the action item to zero. Actionlist items acting on ITSO Shells and on IPEs which do not contain a Value Group shall only be used where multiple actioning of the item is of no consequence

For Actionlist items acting on IPEs containing a Value Group, the process followed by HOPS and POST is as follows:

- On creating an IPE instance, the value of action ActionSequenceNumber shall be set to 0, the IPA subsequently created shall contain the same value
- When an Actionlist item is generated in the HOPS, the current value of ActionSequenceNumber shall be obtained from the IPA and stored in the Actionlist item
- When the POST attempts to action an Actionlist item
  - If the Actionlist item ActionSequenceNumber value is not equal to the IPE instance ActionSequenceNumber, then the Actionlist item shall not be actioned
  - Otherwise, If the Actionlist item ActionSequenceNumber value is equal to the IPE instance ActionSequenceNumber, then the POST shall
    - do the action
    - Increment the value of ActionSequenceNumber held in the IPE instance
    - Return the new value of IPE instance action ActionSequenceNumber in the Transaction Record
- When the HOPS receives the Transaction Record generated as a result of the actioning of the Actionlist item, it shall update the IPA with the new value of ActionSequenceNumber. For the avoidance of doubt, the IPA's ActionSequenceNumber shall not be changed in the event of receiving an unsuccessful Actionlist Match Event message.

Note: Prior to version 2.1.4 of the specification ITSO did not provide a mechanism which prevents Actionlist items which create IPEs (where ActionToTake = 1) from being actioned more than once. Prevention of multiple actioning was the responsibility of the Product Owner. Clause 7.5.3.4 was added to provide for an alternative methodology which overcomes this limitation.

Following use of ActionSequenceNumber = 255, the element shall rollover to zero (0).

### 7.5.3.3 Actionlist types

Various types of actions may be instigated by the HOPS. These are defined in ITSO TS 1000-6.

#### 7.5.3.4 IPE\_Fulfilment\_Action Generation

Any HOPS that supports the use of the IPE\_Fulfilment\_Action shall be able to carry out the following:

1. The HOPS shall be responsible for assembling the business requirements for the form factor and data content of the IPE\_Fulfilment\_Action. These may be derived from sources outside the scope of ITSO (e.g. RSP ITSO fulfilment service) or alternatively from IPE embodiment parameters.
2. Create the IPE\_Fulfilment\_Action by using
  - a. The form factor and data content assembled in item 1 (above)
  - b. Details of the target Shell acquired from the Shell owner (see TS1000-6 clause 9.6)

- c. The functionality provided by a retail POST having an ISAM, with the necessary permissions to create the IPEs to be fulfilled and complying with the business requirements
- d. Delivery of advance notification of impending fulfilment to Shell and IPE Owners
- e. Delivery of the IPE\_Fulfilment\_Action to another HOPS

A Service Provider's first line HOPS shall deliver the IPE\_Fulfilment\_Action to the relevant Fulfilment POSTs under its control

## **7.6. Loyalty schemes**

The HOPS shall provide support for the operation of loyalty schemes.

### **7.6.1 Loyalty scheme types**

The HOPS shall support two types of scheme defined as follows:

- Type 1 - A Customer Media based scheme where loyalty points are stored in the IPE instance
- Type 2 - An Account based scheme where points are held only in the IPA

### **7.6.2 Loyalty scheme operation**

ITSO does not prescribe how loyalty schemes should operate, apart from the minimum requirements defined in the subsequent clauses.

### **7.6.3 Deferred Use Loyalty IPEs**

ITSO Shells may contain a Loyalty IPE instance, but this may initially not be used. Under these circumstances the associated IPA need not be created until the IPE instance is first used. The POST shall indicate to the HOPS that a first use of Loyalty has occurred, using the appropriate message defined in ITSO TS 1000-6, and at that point the IPA shall be created.

## **7.7 IPE Embodiment Specifications**

Embodiment specifications define the IPE Owner defined parameters necessary for the creation of IPE instances. They are defined in ITSO TS 1000-6, in the form of IPE Embodiment Parameter Lists.

The HOPS shall provide facilities for:

- The creation of embodiment specifications for each IPE embodiment which the IPE Owner requires to be supported by the HOPS
- The storage of such embodiment specifications
- The update of such embodiment specifications
- Marked for deletion
- The transmission of such embodiment specifications to POSTs and to other HOPS for the purpose of creating IPEs

The messages for transmitting embodiment specifications to other HOPS are defined in ITSO TS 1000-6.

## 8. Asset Management System (AMS)

The AMS is an optional component. As stated in clause 1, the AMS component is not required in every instance of a HOPS, but within a given ITSO Compliant Scheme there shall exist one or more HOPS containing said AMS component.

### 8.1 AMS overview

#### 8.1.1 General

As its name implies, the AMS component provides the resources to allow asset administrators to manage and control certain assets within the ITSO Compliant Scheme which are required to support the interoperable smart Customer Media environment defined by ITSO. These assets comprise:

- The physical ISAMs and HSAMs
- The centrally (ISMS) controlled Acceptance and Capability Criteria tables stored within the (managed) ISAMs and HSAMs
- The locally controlled Acceptance and Capability Criteria tables stored within the (managed) ISAMs and HSAMs
- The POST-stored POST configuration data

Sub-clauses 8.2 to 8.5 define the AMS requirements for handling each of these asset types in detail.

The AMS shall provide the same management services for HSAMs under its control as for ISAMs. Unless otherwise noted, where a requirement for the AMS is stated against managed ISAMs, then this requirement shall also apply against managed HSAMs.

#### 8.1.2 ISMS interface

The AMS acts as a 'client' to the ISMS 'server' role. The AMS client shall issue request messages to the ISMS server. Two categories of request shall be supported:

• ISMS Information Request	Via Data Frames in Class 2 messages
• ISMS Security Request	Via Secure Data Frames in Class 3 messages

The AMS shall issue ISMS Information Requests when it requires the ISMS to provide data that is not security access key or security related.

The AMS shall issue ISMS Security Requests when it requires the ISMS to provide key or security related data.

The ISMS will respond to the above requests with one or more response messages. Two categories of response are supported:

• ISMS-AMS Information Packet	Via Data Frames in Class 2 messages
• ISAM Security File	Via Secure Data Frames in Class 3 messages

The ISMS-AMS Information Packet mechanism will be used for providing responses to requests from the AMS and for transferring general notification and alert information. The AMS shall be capable of receiving this general information and presenting it to the asset administrator in a clear and timely manner, such that the administrator is able to fulfil their obligations defined by the ITSO Business Rules.

The ISMS will only generate ISAM Security Files in response to ISMS Security Requests for security-related data from the AMS. In most cases the ISMS generated ISAM Security Files will be directed to one or more ISAMs under

the AMS's control. However, if the HSAM within the HOPS requires security updates, then the ISAM Security File will be directed to the HSAM in question.

ISAM or HSAM generated ISAM Security Acknowledgements in response to the ISMS Security Files will be routed to the ISMS via the message handler function of the HOPS.

Clause 8.5.1 details the ISMS interface further.

## **8.2 Physical ISAM / HSAM**

The ISAM is an ITSO-supplied security sub-system, and is one of the main technical security components within the ITSO Environment. Every POST is fitted with an ISAM. Refer to ITSO TS 1000-7 for further details of role and scope of the ISAM security sub-system.

The HSAM is the security sub-system fitted in every HOPS (see clause 4).

### **8.2.1 General**

As the ISAM / HSAM is a critical component of the ITSO Environment, certain attributes of it shall be recorded and maintained in an accurate state by the AMS. These attributes are:

- The ISAM / HSAM serial number
- The legal entity that owns the ISAM / HSAM
- The contact details for the person within said legal entity who is responsible for ISAM / HSAM control & management
- The ITSO OID assigned to said legal entity
- The date of commissioning of the ISAM / HSAM
- The date of decommissioning of the ISAM / HSAM
- The ISAM / HSAM password

### **8.2.2 POST allocation**

Each instance of a POST within an ITSO Environment shall be fitted with an ISAM. As the ITSO operation of a given POST is defined to a significant extent by the data within its ISAM, the AMS shall provide the capability to assign, maintain and monitor for each ISAM:

- Installation status of the ISAM
- The operational location of the POST in which said ISAM is fitted
- The serial number / identification of the POST in which the ISAM is fitted
- The type of POST
- The contact details for the person who is responsible for the POST equipment

The "Type of POST" element shall be designed such as to enable the following to be recorded:

- generic type, e.g. point of sale, validator, or a personaliser
- manufacturer identity
- manufacturer's type number; and
- hardware, firmware, software versions

The miscellaneous message entitled; POST Information Notification, message code 0803, shall be supported by the (AMS) HOPS as a means to assist in the maintenance and monitoring of each ISAM. It is considered informative to the (AMS) HOPS and may be used as required to enhance the effective management of the ISAMs / HSAMs under its control.

### 8.2.3 HOPS allocation

Each instance of a HOPS within an ITSO Environment shall be fitted with an HSAM. The AMS shall provide the capability to assign, maintain and monitor for each HSAM:

- Installation status of the HSAM
- The operational location of the HOPS in which said HSAM is fitted
- The serial number / identification of the HOPS in which the HSAM is fitted
- The type of HOPS
- The contact details for the person who is responsible for the HOPS

### 8.2.4 ISAM / HSAM state

The AMS shall provide the capability to maintain and monitor the state of each ISAM / HSAM for which it is responsible. The state shall be one of:

- Not Deployed
- Deployed but Not Yet In Service
- In Service – Operational
- In Service - Lost / Stolen
- In Service – Faulty
- In Service - Not owned
- In Service – Suspended
- Deployed but taken Out Of Service
- Returned and stored
- Not yet in service – lost/stolen
- Not yet in service – faulty
- Not yet in service – not owned
- Not yet in service – suspended
- Unknown
- Hotlisted
- Destroyed

### 8.2.5 ISAM / HSAM memory management

The AMS plays an important role in the allocation and management of the memory within ISAMs / HSAMs under its control. The AMS shall be capable of:

- Generating the required ISAM Security Files to create the locally controlled Acceptance and Capability Criteria tables on the ISAM / HSAM
- Generating the required ISAM Security Files to create the required centrally controlled Acceptance and Capability Criteria tables on the ISAM / HSAM
- Setting up and maintaining the required indexes between locally controlled Acceptance and Capability Criteria tables on the ISAM / HSAM
- Setting up and maintaining the required indexes between locally and centrally controlled Acceptance and Capability Criteria tables on the ISAM / HSAM



- Setting up and maintaining the required indexes between the Acceptance and Capability Criteria tables and the 'internal counter functions' on the ISAM / HSAM

The above means that the AMS is required to maintain an image of the memory allocation and table linkages for each ISAM / HSAM under its control. Note for tables populated by the ISMS this image will only reflect the structural aspects and does not include the actual data stored in said tables.

See ITSO TS 1000-7 and ITSO TS 1000-8 for details of the required memory structure and the command scripts used with ISAM Security Files to establish and maintain said structure.

#### 8.2.5.1 ISAM management messaging requirements

The AMS shall create files in the ISAMs and HSAMs it manages sufficient for the storage of the following:

- Physical ISAM Group sequence numbers and ISAM sequence numbers
- A file for the storage of a log of Secure Acknowledgements
- A file indexing the last Secure Acknowledgement stored per message

These files shall be created as defined in TS1000– 8

Only the AMS HOPS shall be able to populate the sequence number file.

In order to manage the application of Secure Data Frames to the ISAM the POST application shall be able to select and read all of the above files whilst also being able to write to the log and index files.

##### 8.2.5.1.1 Normal Message composition rules

The AMS HOPS shall compose class 3 messages and set the values of the Group\_Message\_Seq# and ISAM\_Message\_Seq# in accordance with the following rules:

1. All the Secure Data Frames needed to carry out a self-contained action on an ISAM or Physical group of ISAMs shall be packed in the correct sequence in a single class 3 message. The first Frame to be applied by the target I/HSAM shall be the first Frame in the message. The final scripts in the last Secure Data Frame in the message shall update the ISAM Group Seq# and the ISAM Seq# as defined in table 1 and are stored in the ISAM LOG1\_SEQ# file.
2. Messages that update a Group of ISAMs shall not be dependent on any previously applied update to a single member of the Group unless a single update, with the same dependency but not necessarily the same content, is applied to all members of the Group.
3. Messages intended for application to a single ISAM within a Group unconditional on any previously applied Group updates shall have the Group\_Message\_Seq# set to 0.
4. Messages intended for application to a single ISAM within a Group that are dependent upon the presence of a previously applied Group update shall have the Group\_Message\_Seq# set equal to the latest ISAM\_Group\_Seq#.
5. Messages intended for application to a Group of ISAMs unconditional on any previously applied updates to a single member ISAM shall have the ISAM\_Message\_Seq# set to 0
6. In order for new Frames to be applied to an ISAM at least one of the sequence numbers in the message shall be set to one greater than the equivalent number stored in the ISAM.
7. The ISAM will not action Secure Data Frames that have a DTS containing a Day count earlier than the Certified DTS held by the ISAM. Thus, the AMS HOPS shall ensure that all Secure Data Frames in messages:
  - a. Either: All carry a DTS from the same day in which case they can be positioned in the message in any order consistent with good practice
  - b. Or If not: The Secure Data Frames with a DTS containing a later or earlier day are positioned after or before the others respectively.

**Table 1 - Updating the ISAM Group Seq# and the ISAM Seq#**

<b>Message Seq#(s)</b>	<b>Final script(s) shall be coded to SET the ISAM Seq#(s) as shown below</b>
Group_Message_Seq# = 0	ISAM_Seq# = ISAM_Message_Seq#
ISAM_Message_Seq# = 0	ISAM_Group_Seq# = Group_Message_Seq#
Group_Message_Seq# = ISAM_Group_Seq#	ISAM_Seq# = ISAM_Message_Seq#
Group_Message_Seq# = 1+ ISAM_Group_Seq#	ISAM_Group_Seq# = Group_Message_Seq# AND ISAM_Seq# = ISAM_Message_Seq#
Group_Message_Seq# = ISAM_Group_Seq# AND ISAM_Message_Seq# = ISAM_Seq#	No script(s) needed

Annex B of Part 3 gives an example of a typical progression of sequence numbering.

#### **8.2.5.1.2 DTS Message composition rules**

Periodically the AMS HOPS may wish to supply a Keep Alive Message to update the Certified Date in ISAMs it manages independently from the updates caused by the application of Secure Data Frame updates using normal messages as defined in clause 8.2.5.1.1. This message shall be composed of a single Secure Data Frame and generated in accordance with the following rules:

1. The TDF Data Element in the Secure Data Frame shall have bit2 set to one (1)
2. The Secure Data Frame shall be composed of any benign script. (e.g. "Select the ISAM MF") and shall not contain any scripts designed to update the ISAM Group Seq# and/or the ISAM Seq# stored in the ISAM.
3. The message shall have the Group\_Message\_Seq# and ISAM\_Message\_Seq# Data Elements set to match the values of ISAM Group Seq# and ISAM Seq# stored in the target ISAM.

### **8.2.6 ISAM grouping**

#### **8.2.6.1 Physical ISAM Groups**

The AMS shall provide the capability to assign ISAMs to Physical ISAM Groups.

Note: An ISAM may only be allocated to one Physical ISAM Group within the ISMS.

#### **8.2.6.2 Logical ISAM Groups**

It is recommended that the AMS provides the capability to assign individual ISAMs to logical ISAM Groups. Individual ISAMs may belong to one or more Logical ISAM Groups.

#### **8.2.6.3 ISAM Group Functions**

The provisions of this sub-clause apply to both Physical ISAM Groups and Logical ISAM Groups.

The asset administrator will determine the assignment of ISAMs to groups. The AMS shall support user defined naming of ISAM groups.

The AMS shall allow actions to be performed on groups of ISAMs, unless said action is specifically prohibited (by the ISMS) for group usage.

Note: Group operations that involve indexing require that all ISAMs in the group use the same index value. This requirement must be accommodated by the ISAM memory management functionality of the AMS.

Note: All ISAMs within a group shall have the same USE (as defined in ITSO TS1000–8).

### 8.3 Centrally controlled Acceptance and Capability Criteria tables

As defined in ITSO TS 1000-7, the ISAM / HSAM functionality is partly defined by a set of tables collectively known as the Acceptance and Capability Criteria. Each table controls a certain aspect of the ISAM / HSAM operation as defined in ITSO TS 1000-8.

Some of these tables are populated by the central ISMS system. These centrally controlled tables enforce the ITSO Environment-wide settings, such as keys, Customer Media platforms, etc.

The centrally controlled tables are:

- ISAM Header Record
- ISAM Data
- ISAM Groups (Physical)
- Customer Media Codes
- Transaction Keys
- Access Keys
- IPE Keysets
- ISAM Instances
- RSA Public Keys
- RSA Private Keys

As stated in clause 8.2.4, the AMS is required to generate the required ISAM Security Files to create a number of these tables, and to maintain the indexing of records across certain tables as defined in ITSO TS 1000-7 and ITSO TS 1000-8.

Population of these centrally controlled tables will be by data provided by the ISMS in ISAM Security Files. As stated previously, the ISMS only provides ISAM Security Files in response to ISMS Security Requests for data from the AMS that is responsible for the ISAM.

The required ISAM Security Files will be sent from the ISMS to the relevant HOPS. The HOPS does not need to do any processing of the constituent Secure Data Frames, other than enclosing them in Class 3 messages addressed to individual ISAMs and routing said messages to the required POST (or to the required HOPS in the case of HSAM destined files).

ISAM Security Acknowledgements generated in response to the received ISAM Security File will be destined to the ISMS, routed via the HOPS. Again, the HOPS does not need to do any processing of these Secure Data Frames, other than enclosing them in Class 3 messages addressed to the ISMS.

See also ITSO TS 1000-9 for further details on Class 3 messaging.

### 8.4 Locally controlled Acceptance and Capability Criteria tables

As well as the centrally controlled tables defined in the previous clause, the ISAM's Acceptance and Capability Criteria also contains a number of locally controlled tables. In this context local means directly by the AMS responsible for the ISAM / HSAM.

These locally controlled tables enforce the scheme-specific commercial requirements such as: Physical ISAM grouping, accepted IPEs, POST revalidation capability, etc.

Locally controlled tables are:

- ISAM Configuration
- IPEs Accepted
- Criteria
- Limits List

As stated in clause 8.2.4, the AMS is required to generate the required ISAM Security Files to create these tables, and to maintain the indexing of records across certain tables as defined in ITSO TS 1000-7 and ITSO TS 1000-8.

Population of these locally controlled tables will be by data provided by the AMS in ISAM Security Files. These ISAM Security Files will take the form of AMS-generated Class 3 messages directed to the ISAM. The ISMS is not involved in the generation of these ISAM Security Files.

ISAM Security Acknowledgements generated in response to the received ISAM Security Files will be destined to the AMS.

#### 8.4.1 ISAM Configuration

The AMS shall be able to configure and control the following parameters within this table:

- Maximum allowed attempts for presentation of ISAM password
- ISAM password
- Transaction Record storage mode (whether records are stored in the ISAM or not)

See ITSO TS 1000-8 for the detailed data formats of these parameters.

#### 8.4.2 Physical ISAM Groups

The AMS shall be able to configure and control records within this table. Each record corresponds to a Physical group to which the ISAM belongs. Each record contains the following fields:

- AMS defined Physical group number
- Record revision number
- Valid from date
- Valid until date
- Issuer identifier (IIN)
- ISAM ID / OID
- Index to the RSA Public Key record<sup>16</sup> that is used for this grouping

See ITSO TS 1000-8 for the detailed data formats of these fields.

#### 8.4.3 IPEs Accepted

The AMS shall be able to configure and control records within this table. Each record corresponds to an IPE embodiment that the ISAM is authorised to accept. Each record contains the following fields:

- AMS defined record number
- Record revision number
- Valid from date

---

<sup>16</sup> See clause 8.3

- Valid until date
- IIN of Product Owner
- OID of Product Owner
- TYP
- PTYP
- IPE format revision
- KID
- Index to the IPE Keysets<sup>17</sup> record that is used for this IPE embodiment
- Index to the Criteria record<sup>18</sup> that is used for this IPE embodiment
- See ITSO TS 1000-8 for the detailed data formats of these fields

#### 8.4.4 Criteria

The AMS shall be able to configure and control records within this table. Each record corresponds to a set of ISAM criteria options used against IPE operations. Each record contains the following fields:

- AMS defined record number
- Record revision number
- Valid from date
- Valid until date
- ISAM schedules to be executed
- IPE operations allowed
- Index to the Limits List<sup>19</sup> record that is used for this criteria set

See ITSO TS 1000-8 for the detailed data formats of these fields.

#### 8.4.5 Limits List

The AMS shall be able to configure and control records within this table. Each record corresponds to a set of limits used against IPE operations. Each record contains the following fields:

- AMS defined record number
- Record revision number
- Valid from date
- Valid until date
- Maximum number of IPE creations allowed in a given Transaction Session Batch
- IPE creation warning level
- Maximum value which may be added in a given Transaction Session Batch

---

<sup>17</sup> See clause 8.3

<sup>18</sup> See clause 8.4.4

<sup>19</sup> See clause 8.4.5

- IPE value addition warning level
- Index to the internal counter function used

See ITSO TS 1000-8 for the detailed data formats of these fields.

## **8.5 POST stored POST configuration data**

The AMS is also responsible for maintaining the POST configuration data stored within POSTs under its control. The POST configuration data is the collective term given to a number of parameter tables each of which controls a certain aspect of interoperability.

ITSO TS 1000-6 defines the required data content for each of the tables.

ParameterTableIdentifier shall be managed by the First Line HOPS, such that each list sent to a POST contains the same value for this element. It should be noted that this means that the value of ParameterTableIdentifier contained in Parameter Tables received from other HOPS shall be changed to a value assigned by the First Line HOPS.

### **8.5.1 Term Dates**

The AMS shall maintain the 'Term Dates' parameter table for each Product accepted by a POST that requires this information to be available.

### **8.5.2 Peak times**

The AMS shall maintain the 'Peak Times' parameter table for each product accepted by a POST that requires this information to be available.

### **8.5.3 Day type assignment**

The AMS shall maintain the 'Day type assignment' parameter table for each product accepted by a POST that requires this information to be available.

### **8.5.4 Transfers**

The AMS shall maintain the 'Transfers' parameter table for each product accepted by a POST that requires this information to be available.

### **8.5.5 Rebates**

The AMS shall maintain the 'Rebates' parameter table for each product accepted by a POST that requires this information to be available.

### **8.5.6 Loyalty**

The AMS shall maintain the 'Loyalty Rules' parameter table for each product accepted by a POST that requires this information to be available.

### **8.5.7 Exchange rates**

The AMS shall maintain the 'Currency' parameter table that defines exchange rates between currencies accepted by a POST.

### 8.5.8 Zones

The AMS shall maintain the 'Zone Table Reference' parameter table for each product accepted by a POST that requires this information to be available.

#### 8.5.8a Zone Table Bitmap

The AMS shall maintain the 'Zone Table Bitmap' parameter table for each relevant product by a POST that requires this information to be available.

### 8.5.9 Sale price

The AMS shall maintain the 'Sale Price' parameter table for each product accepted by a POST that requires this information to be available.

### 8.5.10 IIN index

The AMS shall maintain the 'IIN' parameter table for each IIN that is accepted by the POST.

### 8.5.11 IPE Embodiment parameters

The AMS shall maintain the 'IPE' parameter table for each product type that a POST is authorised to be able to create an instance of.

### 8.5.12 ISAM Management File Parameters

The AMS shall maintain the 'ISAM Management File Parameters' parameter table for each POST that requires this information to be available.

### 8.5.13 Passback Times

The AMS shall maintain the 'Passback Times' parameter table for each product accepted by a POST that requires this information to be available.

### 8.5.14 HOPS PCD and Manifest application rules

The rules and application logic the HOPS shall apply for PCD are defined in this clause.

The HOPS shall apply the following rules:

1.	The first line HOPS shall maintain a manifest of all the tables and content pertaining to the PCD required by every POST under its control.
2.	The HOPS shall ensure that all entries in a particular parameter table shall be subservient to a single value of the ParameterTableIdentifier.
3.	The HOPS shall ensure that all entries in a particular parameter table shall have the same FormatRevision number.
4.	The HOPS application shall ensure that:
a.	If the IndexNumber Data Element is present. Each entry in a parameter table shall be referenced by an Index of increasing value that may be used by the POST application, either alone or in conjunction with,

		the wild card entry handling rules to determine the order of processing of the entries.
		In this case an entry having lower IndexNumber wherever it appears in a selection from the Parameter tables being used by the POST application shall be processed before an entry having a greater IndexNumber.
	b.	If the table has no IndexNumber Data Element present the entries shall be ordered in priority of rules for execution with the highest priority at the start of the table. If priorities are subsequently changed then the complete updated table or tables shall be sent to the POST.
	Note: Where there are two (or more) possible matches all of which are based on wildcards, then the following rules of preference, ordered 1 to 3, shall apply:	
	1.	Match based on PTYP = wildcard (IIN/OID & TYP are defined)
	2.	Match based on TYP = wildcard (IIN/OID is defined & PTYP is either defined or a wildcard)
	3.	Match based on IIN/OID = wildcard (TYP & PTYP either defined or wildcard)
5.	Updates to a Parameter Table may be carried out by overwriting existing records as referenced by IndexNumber or by appending further records with a new index number or a combination of both. Any updates to a Parameter Table shall require the HOPS to re compute and update the HASH associated with that table that is included in the Manifest. As a consequence, the Hash of the Manifest itself shall be recomputed and also included in the Manifest.	
6	If a POST is allocated to a SET for the purposes of delivering PCD then:	
	<ul style="list-style-type: none"> <li>• A POST can only belong to a single Set defined for that purpose</li> </ul>	
	<ul style="list-style-type: none"> <li>• All POSTs within that SET always have the same PCD configuration</li> </ul>	
	Note: An individual POST may be allocated to another SET for a different purpose for example; the delivery of action lists. This may affect the contents and use of the 0600 and 0B00 message.	

### 8.5.15 Sending of PCD from a HOPS

The following rules shall apply to the delivery of PCD from a HOPS.

#### 8.5.15.1 HOPS to HOPS

It is recognised that PCD may be derived from a message received from another HOPS. For example, the HOPS of a product owner may wish to send PCD to a service operators HOPS.

The following rules shall apply:

1. The HOPS shall ensure that all PCD updates relating to a complete business requirement shall be grouped together and delivered to the receiving HOPS in a single message.
2. A product owners HOPS sending PCD to another HOPS shall only send tables as required from the following list:

Code	Parameter Table
0A01 / 0B01	Term dates
0A02 / 0B02	Peak Times
0A03 / 0B03	Day Type Assignment



0A04 / 0B04	Transfers
0A05 / 0B05	Rebates
0A06 / 0B06	Loyalty Rules
0A0A / 0B0A	Sale price table
0A0C / 0B0C	Embodiment parameters
0A0E / 0B0E	Passback Times

Note: It is recognised that where IPE usage is conditioned by geographical Zone information, the first line HOPS shall create the necessary PCD for the POSTS under its control based on a business agreement with the IPE owner. As a consequence, inter HOPS notification of Zone information using Zone Table messages is not required.

1. A product owner's HOPS sending PCD to another HOPS shall not use wild cards in any Data Element containing an OID.
2. A HOPS having an AMS function sending PCD to another HOPS may in addition send the following table.

Code	Parameter Table
0A0D / 0B0D	ISAM management file parameters

### 8.5.15.2 HOPS to POST

The Service operator's first line HOPS shall always be responsible for collating all the PCD for POSTs under its control. This shall include the ability to:

- create and populate all parameter tables it requires
- order the content and indexing of all parameter tables
- set all Data Element wild cards in the most appropriate manner for its POSTs or Sets of POSTs

The following rules shall apply:

1. The first line HOPS shall ensure that all PCD updates relating to a complete business requirement shall be grouped together and where possible delivered to the POST in a single message. The final update included in the message shall be the entire Manifest table.
2. The first line HOPS shall be able to instigate the delivery of updates to a table in the PCD or the entire PCD to a POST, or SET of POSTS all having the same PCD.
3. The first line HOPS shall, at any time, respond to a request from a POST to deliver the PCD for that POST in all or in part. If this includes partial delivery of a complete business update the POST application shall not action the update until a valid Manifest is received. To instigate this action the POST sends an 0803 message to the HOPS and if the indicated state of the PCD for that POST does not match that recorded in the HOPS then the PCD is sent to the POST.

## 8.6 AMS interfaces

The AMS component shall interface to:

• The ISMS	(via the Message Processing HOPS component)
• The managed ISAMs / HSAMs	(via the Message Processing HOPS component)

• The managed POSTs	(via the Message Processing HOPS component)
• The asset administrator	(via a human interface)

The AMS function makes use of all the mandatory HOPS components (message processor, message store, HSAM and services) in its operation.

In particular the AMS function uses the HOPS message processor to communicate with the ISMS, the HSAM and via the POSTs the installed ISAMs.

### 8.6.1 ISMS

The ISMS provides security-related data to the AMS only when so requested by the AMS. In this mode, the ISMS acts as a “server” to the AMS “client”.

There is also a need for the ISMS to distribute (centrally held) information to AMS systems within the ITSO Environment. Typical examples are when the ITSO Registrar has made changes (via the ISMS) to the list of Licensed Members, Products and supported customer media platforms. In these cases the ISMS will issue the required informative messages to affected AMSs. As a result of the receipt of these informative messages, the AMS may be required to request updated security-related data in the manner described above.

The AMS shall support the following data transfers between itself and the ISMS:

- ISMS Security Requests sent from the AMS to the ISMS
- ISMS Information Requests sent from the AMS to the ISMS
- ISAM Security Acknowledgements sent from the AMS to the ISMS
- AMS Information Acknowledgements sent from the AMS to the ISMS
- ISAM Security Files sent from the ISMS to the AMS
- ISMS-AMS Information Packets sent from the ISMS to the AMS

#### 8.6.1.1 ISMS Security Requests

The AMS shall support the following types of ISMS Security Requests:

- ISMS\_SREQ\_ISAM\_CHANGES
  - ISMS\_SREQ\_ISAM\_DATA
  - ISMS\_SREQ\_STATE\_CHANGE
- ISMS\_SREQ\_KEY\_REQUEST
  - ISMS\_SREQ\_IPE\_KEYS
  - ISMS\_SREQ\_DIR\_KEY
  - ISMS\_SREQ\_KEYRING
  - ISMS\_SREQ\_CM
  - ISMS\_SREQ\_ISMS\_PUBLIC\_KEY
  - ISMS\_SREQ\_HOPS\_PUBLIC\_KEY
  - ISMS\_SREQ\_ISAM\_PUBLIC\_KEY
- ISMS\_SREQ\_ISAM\_PROGRAM\_UPDATE
- ISMS\_SREQ\_ASSYM\_KEYS
- ISMS\_SREQ\_IMPORT\_CM\_KEYS

ISMS Security Requests shall be formatted as XML files. ITSO TS 1000-9 defines the DTD for these files.

ISMS Security Requests shall be secured using a 'hash & MAC' mechanism. The message hash shall be generated by the AMS, which shall then use the services of the HSAM to generate an associated MAC. This mechanism is defined in ITSO TS 1000-8.

#### 8.6.1.1.1 ISMS\_SREQ\_ISAM\_DATA

This requests the ISMS to provide the control data for the specified ISAM / HSAM. Within the request the AMS shall provide:

- ISAM Reference Number (IRN)
- ISAM Usage
- OID
- AMS Identity<sup>20</sup>

If the request is approved, the ISMS will respond with an ISAM Security File containing the required information. This message will be sent to the HOPS, which shall route it to the required ISAM / HSAM.

The ISMS shall also send an Information Packet message to the AMS containing the assigned ISAM\_ID<sup>21</sup>. The AMS shall use this ISAM\_ID for all further referencing of the ISAM / HSAM.

If the request is denied, then the ISMS will provide the AMS with reasons for said denial via an ISMS-AMS Information Packet message<sup>22</sup>.

Notes:

- 1) The ISMS\_SREQ\_ISAM\_DATA message will only be accepted by the ISMS once for a given IRN.
- 2) The IRN is defined at time of ISAM / HSAM manufacture and is printed on the device.
- 3) The allowed values for ISAM Usage are: POST delete Products allowed, POST delete products not allowed, SHELL PERSONALISER, HOPS. These are represented as bit settings in a USE byte defined in ITSO TS 1000-8, ISAM Data table.
- 4) OID shall be the OID to which the ISAM / HSAM is to be assigned to. Once set, this cannot be changed.
- 5) AMS Identity shall identify the AMS to which the HSAM is to be assigned.
- 6) Multiple ISMS\_SREQ\_ISAM\_DATA requests may be sent within an ISMS\_SREQ\_ISAM\_CHANGES message

#### 8.6.1.1.2 ISMS\_SREQ\_STATE\_CHANGE

This requests the ISMS to change the recorded state of the specified ISAM / HSAM. Within the request the AMS shall provide:

- IIN
- ISAM\_ID
- Required State

If the request is approved, the ISMS will respond with an ISAM Security File. This message will be sent to the HOPS, which shall route it to the required ISAM / HSAM.

If the request is denied, then the ISMS will provide the AMS with reasons for said denial via an ISMS-AMS Information Packet message.

---

<sup>20</sup> For HSAMs only

<sup>21</sup> See clause 8.6.1.6.12

<sup>22</sup> Of type ISMS\_INFO\_SECURITY\_REQUEST\_DENIED

Notes:

- 1) The allowed values for Required State are: LOSTSTOLEN, OPERATIONAL, FAULTY, OUTOFSERVICE (as text).
- 2) Multiple ISMS\_SREQ\_STATE\_CHANGE requests may be sent within an ISMS\_SREQ\_ISAM\_CHANGES message

#### 8.6.1.1.3 ISMS\_SREQ\_IPE\_KEYS

This requests the ISMS to provide the required keys for a given IPE embodiment. Within the request the AMS shall provide:

- Required destination (ISAM or Physical ISAM group)
- IIN of the Product Owner of the IPE in question
- OID of the Product Owner of the IPE in question
- TYP code of the IPE in question
- PTYP code of the IPE in question
- IPE Format Revision (IFR) of the IPE in question
- Key ID (KID) of the IPE in question
- Index for the IPE Keyset table
- Proxy ISAM<sup>23</sup>reference identifier<sup>24</sup>
- FN\_S reference
- Request type (Add or Remove IPE keys)

If the request is approved, the ISMS will respond with an ISAM Security File containing the required information. This message will be sent to the HOPS, which shall route it to the required ISAM(s).

If the request is denied, then the ISMS will provide the AMS with reasons for said denial via an ISMS-AMS Information Packet message.

Notes:

- 1) The IPE Keyset table index is in the form table id + record index. The allowed values for the table id are 00 to 03. (The ISMS will then calculate the actual table id from this value). The allowed values for the record index are 00 to 253. E.g. an allowable value is 0001 where the table id is 00 and the record index is 01.
- 2) The allowed values for FN\_S reference are: 1100 to 14FF (hex values).
- 3) Multiple ISMS\_SREQ\_IPE\_KEYS requests may be sent within an ISMS\_SREQ\_KEY\_REQUEST message

#### 8.6.1.1.4 ISMS\_SREQ\_DIR\_KEY

This requests the ISMS to provide the required keys for the ITSO Directory. Within the request the AMS shall provide:

- Required destination (ISAM or Physical ISAM group)
- IIN of the ITSO Directory owner<sup>25</sup>

---

<sup>23</sup> If ISAM is authorised to retail the IPE in question

<sup>24</sup> Proxy ISAM reference cannot be used for a group-based command

<sup>25</sup> This is 633597 (coded as BCD)

- OID of the ITSO Directory owner<sup>26</sup>
- Key ID (KID)
- Index for IPE Keyset table

If the request is approved, the ISMS will respond with an ISAM Security File containing the required information. This message will be sent to the HOPS, which shall route it to the required ISAM(s).

If the request is denied, then the ISMS will provide the AMS with reasons for said denial via an ISMS-AMS Information Packet message.

Notes:

1) The allowed values for the IPE Keyset table index are: The IPE Keyset table index is in the form table id + record index. The allowed values for the table id are 00 to 03. (The ISMS will then calculate the actual table id from this value). The allowed values for the record index are 00 to 253. E.g. an allowable value is 0001 where the table id is 00 and the record index is 01.

2) Only one ISMS\_SREQ\_DIR\_KEY request may be sent within an ISMS\_SREQ\_KEY\_REQUEST message

#### 8.6.1.1.5 ISMS\_SREQ\_KEYRING

This requests the ISMS to provide the environment-wide keys. Within the request the AMS shall provide:

- Required destination (HSAM, ISAM or Physical ISAM group)
- Key ID (KID)

If the request is approved, the ISMS will respond with an ISAM Security File containing the required information. This message will be sent to the HOPS, which shall route it to the required HSAM(s) / ISAM(s).

If the request is denied, then the ISMS will provide the AMS with reasons for said denial via an ISMS-AMS Information Packet message.

Notes:

1) Only one ISMS\_SREQ\_KEYRING request may be sent within an ISMS\_SREQ\_KEY\_REQUEST message

#### 8.6.1.1.6 ISMS\_SREQ\_CM

This requests the ISMS to provide the required access keys for a given Customer Media platform. Within the request the AMS shall provide:

- Required destination (ISAM or Physical ISAM group)
- IIN of the Shell Owner of the Customer Media platform in question
- OID of the Shell Owner of the Customer Media platform in question
- Format Version Code (FVC) of the Customer Media platform in question
- Key Strategy Code (KSC) of the Customer Media platform in question
- Key Version Code (KVC) of the Customer Media platform in question
- Required keyset (KAS)
- Reference(s) to encrypted key(s)<sup>27</sup>
- Index for the Access Keys table
- Index for the Customer Media Codes table

---

<sup>26</sup> This is FFF8 (hex)

<sup>27</sup> If the CM platform in question requires such keys

- Request type (Add or Remove CM keys)

If the request is approved, the ISMS will respond with an ISAM Security File containing the required information. This message will be sent to the HOPS, which shall route it to the required ISAM(s).

If the request is denied, then the ISMS will provide the AMS with reasons for said denial via an ISMS-AMS Information Packet message.

Notes:

1) Multiple ISMS\_SREQ\_CM requests may be sent within an ISMS\_SREQ\_KEY\_REQUEST message

#### **8.6.1.1.7 ISMS\_SREQ\_ISMS\_PUBLIC\_KEY**

This requests the ISMS to load the ISMS's public key into the specified HSAM / ISAM. Within the request the AMS shall provide:

- Required destination (HSAM or ISAM)

If the request is approved, the ISMS will respond with an ISAM Security File containing the required information. This message will be sent to the HOPS, which shall route it to the required HSAM / ISAM.

If the request is denied, then the ISMS will provide the AMS with reasons for said denial via an ISMS-AMS Information Packet message.

Notes:

1) Only one ISMS\_SREQ\_ISMS\_PUBLIC\_KEY request may be sent within an ISMS\_SREQ\_KEY\_REQUEST message

#### **8.6.1.1.10 ISMS\_SREQ\_HOPS\_PUBLIC\_KEY**

This requests the ISMS to load the public key for the HSAM of the HOPS in question into the specified HSAM / ISAM. Within the request the AMS shall provide:

- Required destination (HSAM or ISAM)
- IIN to which the HSAM whose public key is being requested is registered
- HSAM ID of the HSAM whose public key is being requested

If the request is approved, the ISMS will respond with an ISAM Security File containing the required information. This message will be sent to the HOPS, which shall route it to the required HSAM / ISAM.

If the request is denied, then the ISMS will provide the AMS with reasons for said denial via an ISMS-AMS Information Packet message.

Notes:

1) Only one ISMS\_SREQ\_HOPS\_PUBLIC\_KEY request may be sent within an ISMS\_SREQ\_KEY\_REQUEST message

#### **8.6.1.1.11 ISMS\_SREQ\_ISAM\_PUBLIC\_KEY**

This requests the ISMS to load the public key for the indicated ISAM into the HSAM of the HOPS. Within the request the AMS shall provide:

- Required destination (HSAM)
- IIN to which the ISAM in question is registered
- ISAM ID of the ISAM in question
- HSAM's Asymmetric Key File ID

If the request is approved, the ISMS will respond with an ISAM Security File containing the required information. This message will be sent to the HOPS, which shall route it to the required HSAM.

If the request is denied, then the ISMS will provide the AMS with reasons for said denial via an ISMS-AMS Information Packet message.

Notes:

1) Although only one ISMS\_SREQ\_ISAM\_PUBLIC\_KEY request may be sent within an ISMS\_SREQ\_KEY\_REQUEST message, it is possible to specify multiple ISAM IDs within the request.

#### **8.6.1.1.12 ISMS\_SREQ\_ISAM\_PROGRAM\_UPDATE**

This requests the ISMS to provide a program update for the given ISAM / HSAM. Within the request the AMS shall provide:

- Required destination (ISAM or HSAM)

If the request is approved, the ISMS will respond with one or more ISAM Security Files containing the required program updates, note more than one upgrade may be required if there are more than one program update versions pending. This message will be sent to the HOPS, which shall route it to the required ISAM / HSAM.

If the request is denied, then the ISMS will provide the AMS with reasons for said denial via an ISMS-AMS Information Packet message.

#### **8.6.1.1.13 ISMS\_SREQ\_ASSYM\_KEYS**

This requests the ISMS to provide a RSA key pair. Within the request the AMS shall provide:

- IIN
- Group ID
- List of ISAM IDs to be added/removed from group (optional)
- and for each ISAM the asymmetric file index into which the key is to be stored. Valid file index values are from C003 to CFFF

If the request is approved, the ISMS will respond with an ISAM Security File containing the required information. This message will be sent to the HOPS, which shall route it to the required ISAM(s).

If the request is denied, then the ISMS will provide the AMS with reasons for said denial via an ISMS-AMS Information Packet message.

#### **8.6.1.1.14 ISMS\_SREQ\_IMPORT\_CM\_KEYS**

This requests the ISMS to import and store the provided keys for the given Customer Media. Two types of key import are supported: Import of CM Access Keys in the form of the KAS information and the associated keys information and the import of encrypting keys in the form of a Key Block.

For Access Key import the AMS shall provide:

- IIN of the Shell Owner of the Customer Media platform in question
- OID of the Shell Owner of the Customer Media platform in question
- Format Version Code (FVC) of the Customer Media platform in question
- Key Strategy Code (KSC) of the Customer Media platform in question
- Key Version Code (KVC) of the Customer Media platform in question
- Valid From Date for key
- Valid Until Date for key

- One or more Key Blocks<sup>28</sup>
- One or more KAS Blocks<sup>29</sup>

For Key Block import the AMS shall provide:

- A single Key Block

If the request is approved, the ISMS will import and store the key(s) and respond with an ISMS\_INFO\_NEW\_CM\_NOTIFICATION. This message will be sent to the HOPS.

If the request is denied, then the ISMS will provide the AMS with reasons for said denial via an ISMS-AMS Information Packet message.

### 8.6.1.2 ISMS Information Requests

The AMS shall support the following types of ISMS Information Requests:

- ISMS\_IREQ\_INVENTORY
- ISMS\_IREQ\_CHANGE\_INVENTORY
- ISMS\_IREQ\_MISSING\_ACKS

ISMS Information Requests shall be formatted as XML files. ITSO TS 1000-9 defines the DTD for these files.

ISMS Information Requests shall be secured using a 'hash & MAC' mechanism. The message hash shall be generated by the AMS, which shall then use the services of the HSAM to generate an associated MAC. This mechanism is defined in ITSO TS 1000-8.

#### 8.6.1.2.1 ISMS\_IREQ\_INVENTORY

This requests the ISMS to provide the AMS with a current inventory of ISAMs / HSAMs assigned to the AMS. No parameter is required for this request.

The ISMS will respond with an ISMS-AMS Information Packet message<sup>30</sup>. See section 8.6.1.6.10 for the content of this Information Packet.

#### 8.6.1.2.2 ISMS\_IREQ\_CHANGE\_INVENTORY

This requests the ISMS to update its ISAM / HSAM listing with the details provided by the AMS. Within the request the AMS shall provide:

- Affected devices (HSAM, ISAM, Physical ISAM group)
- Action Code

The ISMS will respond with an ISMS-AMS Information Packet message<sup>31</sup>. See section 8.6.1.6.10 for the content of this Information Packet.

Notes:

1) The allowed values for the Action Code are: REQUEST or RELEASE (as text)

---

<sup>28</sup> A Key Block contains a Key Reference and the actual key value (in an encrypted form)

<sup>29</sup> A KAS Block consists of one or two pairs of Key Flags and Key References. The Key Reference must be unique

<sup>30</sup> Of type ISMS\_INFO\_INVENTORY

<sup>31</sup> Of type ISMS\_INFO\_INVENTORY



### 8.6.1.2.3 ISMS\_IREQ\_MISSING\_ACKS

This requests the ISMS to provide the AMS with details of ISAMs / HSAMs that have not returned a valid ISAM Security Acknowledgement in response to an ISMS generated ISAM Security File. Within the request the AMS shall provide:

- Number of days
- Type

The ISMS will respond with an ISMS-AMS Information Packet message<sup>32</sup>. See section 8.6.1.6.11 for the content of this Information Packet.

Notes:

1) The allowed values for the Type are: MISSING; UNSUCCESSFUL or MISSING\_ UNSUCCESSFUL (as text)

### 8.6.1.3 ISAM Security Acknowledgements

The AMS does not directly generate ISAM Security Acknowledgments.

In the case of an HSAM, the HSAM within the HOPS shall generate security acknowledgements in response to the reception of ISAM Security Files that were destined for the HSAM.

In the case of an ISAM, the ISAM within a POST shall generate security acknowledgements in response to the reception of ISAM Security Files that were destined for the ISAM.

The data within the HSAM / ISAM generated security acknowledgement is encrypted and sealed by the originating node. See ITSO TS 1000-8 for further details.

The HOPS shall accept these security acknowledgements from HSAMs / ISAMs under its control and carry out the required XML framing of these as defined in ITSO TS 1000-9, and then route the resulting ISAM Security Acknowledgments to the ISMS if required.

### 8.6.1.4 AMS Information Acknowledgements

The AMS shall generate an AMS Information Acknowledgement in response to reception of an ISMS-AMS Information Packet message.

AMS Information Acknowledgements shall be formatted as XML files. ITSO TS 1000-9 defines the DTD for these files.

AMS Information Acknowledgements shall be secured using a 'hash & MAC' mechanism. The message hash shall be generated by the AMS, which shall then use the services of the HSAM to generate an associated MAC. This mechanism is defined in ITSO TS 1000-8.

### 8.6.1.5 ISAM Security Files

ISAM Security Files are used to transfer sensitive data from the ISMS to the ISAM / HSAM in a secure manner. The data within the Security File is encrypted and sealed by the ISMS. See ITSO TS 1000-8 for details of the Security File.

The ISMS will frame the encrypted Security File within an XML message as defined in ITSO TS 1000-9, prior to sending it as an ISAM Security File to the AMS that generated the associated ISMS Security Request.

---

<sup>32</sup> Of type ISMS\_INFO\_MISSING\_ACKS

### 8.6.1.6 ISMS-AMS Information Packet

The AMS shall be capable of receiving and processing ISMS Information Packets sent by the ISMS. The AMS shall provide the asset administrator with the received information in a clear and timely manner such that the administrator is able to fulfil their obligations defined by the ITSO Operating License.

Informative data provided by the ISMS will include:

- Notification of the addition of new entities to the ITSO Environment
- Notification of rolling key updates
- Notification of security alerts
- Reasons for denial of ISMS Security Requests

The AMS shall support the following types of ISMS Information Packets:

- ISMS\_INFO\_MEMBER\_NOTIFICATION
- ISMS\_INFO\_NEW\_CM\_NOTIFICATION
- ISMS\_INFO\_NEW\_PRODUCT\_NOTIFICATION
- ISMS\_INFO\_AMENDED\_PRODUCT\_NOTIFICATION
- ISMS\_INFO\_PRODUCT\_WITHDRAWN\_NOTIFICATION
- ISMS\_INFO\_NEW\_KEY\_NOTIFICATION
- ISMS\_INFO\_SECURITY\_ALERT
- ISMS\_INFO\_SECURITY\_REQUEST\_DENIED
- ISMS\_INFO\_REQ\_IN\_PROGRESS
- ISMS\_INFO\_SECURITY\_SCRIPT\_PROCESSING\_FAILED
- ISMS\_INFO\_SERVICE\_NOTIFICATION
- ISMS\_INFO\_INVENTORY
- ISMS\_INFO\_MISSING\_ACKS
- ISMS\_INFO\_NEW\_ISAM\_ID
- ISMS\_INFO\_ISAM\_PROGRAM\_UPDATE\_NOTIFICATION

ISMS-AMS Information Packets will be formatted as XML files. ITSO TS 1000-9 defines the DTD for these files.

ISMS-AMS Information Packets will be secured by the ISMS using a 'hash & MAC' mechanism.

The AMS shall generate an AMS Information Acknowledgement in response to reception of an ISMS-AMS Information Packet message.

#### 8.6.1.6.1 ISMS\_INFO\_MEMBER\_NOTIFICATION

This provides notification of the registration of a new ITSO Licensed Member.

The packet will contain the following pertinent attributes of the new Licensed Member:

- Assigned Licensed Member ID
- Organisation name
- Assigned IIN
- Assigned OID(s)
- Role(s)

#### **8.6.1.6.2 ISMS\_INFO\_NEW\_CM\_NOTIFICATION**

This provides notification of the registration of a new Customer Media platform. ITSO mandates that all POSTs must accept all Customer Media platforms.

The packet will contain the following pertinent attributes of the new platform:

- IIN of the Shell Owner
- OID of the Shell Owner
- Valid From Date
- Valid Until Date
- FVC
- KSC
- KVC
- Description

#### **8.6.1.6.3 ISMS\_INFO\_NEW\_PRODUCT\_NOTIFICATION**

This provides notification of the registration of a new product that must be included in at least one of the ISAMs assigned to a particular AMS.

The packet will contain the following pertinent attributes of the new product:

- IIN of the Product Owner
- OID of the Product Owner
- TYP
- PTYP
- IFR
- KID
- Valid From Date
- Valid Until Date
- Proxy ISAM Reference
- Proxy ISAM ID
- Description
- Product key Valid From Date
- Product key Valid Until Date
- Product Key crypto index

#### **8.6.1.6.4 ISMS\_INFO\_NEW\_KEY\_NOTIFICATION**

This provides notification of a key update. Such updates will usually be due to 'rolling' changes specified by the relevant key owner.

The packet will contain the following pertinent attributes of the new key:

- Description
- IIN of the owner of the key in question
- OID of the owner of the key in question

- Valid From Date
- Valid Until Date
- KID

#### **8.6.1.6.5 ISMS\_INFO\_SECURITY\_ALERT**

This is used to issue a security alert. Reasons for this alert may include:

- Revocation of a License Member
- Revocation of a Customer Media platform
- Revocation of a product
- Detection of fraud

The packet will contain a human readable console message.

#### **8.6.1.6.6 ISMS\_INFO\_SECURITY\_REQUEST\_DENIED**

This is used to inform the AMS that an ISMS Security Request made to the ISMS has been denied.

The packet will contain the following elements:

- Original ID of the request to which the denial relates
- Reason

#### **8.6.1.6.7 ISMS\_INFO\_REQ\_IN\_PROGRESS**

This is used to inform the AMS that an ISMS Security Request made to the ISMS is in progress.

The packet will contain the following elements:

- Original ID of the request to which this message relates
- Reason
- IIN of the HSAM / ISAM device that was provided in the original request
- IRN of the HSAM / ISAM device that was provided in the original request

#### **8.6.1.6.8 ISMS\_INFO\_SECURITY\_SCRIPT\_PROCESSING\_FAILED**

This is used to inform the AMS that an ISMS Security Request script failed to be processed correctly.

The packet will contain the following elements:

- Original ID of the request to which this message relates
- Human readable console message

#### **8.6.1.6.9 ISMS\_INFO\_SERVICE\_NOTIFICATION**

This is used to inform the AMS on the status of the ISMS service.

The packet will contain a human readable console message.

#### **8.6.1.6.10 ISMS\_INFO\_INVENTORY**

This provides a listing of the ISAMs / HSAMs and their groupings (if any) as recorded by the ISMS.

The packet will contain the following elements:

- Original ID of the request to which this message relates
- Group ID
- ISAM\_ID
- ISAM State
- Date of last State change

#### **8.6.1.6.11 ISMS\_INFO\_MISSING\_ACKS**

This provides a listing of the outstanding ISAM Security Acknowledgements for ISAMs / HSAMs under the AMS's control.

The packet will contain the following elements:

- Original ID of the request to which this message relates
- ISAM\_ID
  - ISAM State
  - Date of last State change
  - Number of missing ACKs
- Reason
  - Number of unsuccessful ACKs
- Reason

#### **8.6.1.6.12 ISMS\_INFO\_NEW\_ISAM\_ID**

This provides the assigned ISAM ID for a new HSAM / ISAM.

The packet will contain the following elements:

- Original ID of the request to which this message relates
- Assigned IIN
- Assigned ISAM\_ID
- Assigned Usage
- IRN of device

#### **8.6.1.6.13 ISMS\_INFO\_ISAM\_PROGRAM\_UPDATE\_NOTIFICATION**

This is used to inform the AMS that a new program update is available for its ISAMs.

This packet contains the version information of the new ISAM code release.

#### **8.6.1.6.14 ISMS\_INFO\_AMENDED\_PRODUCT\_NOTIFICATION**

This is used to inform the AMS that a product (IPE) has been amended.

<PRODUCT\_INFO> This element contains values that map to the IPEs Accepted Table in an ISAM.

<IIN> Product's IIN

<OID> Product's OID

<TYP> Type

<PTYP> PType

<IPE\_FORMAT\_REVISION> IFR

<KID> Key Identity

<VFR\_DATE> Valid From Date

<VUT\_DATE> Valid Until Date

<DESCRIPTION> ISMS's Description of product

<PRODUCT\_KEY\_INFO> This is an optional element that contains information about any changes in the associated product key. The elements map to the relevant entry in the ISAM's IPE/DIR Keys table (except <REFERENCE>, which is an ISMS internal reference).

<REFERENCE> ISMS's key reference data

<VFR\_DATE> Valid From Date

<VUT\_DATE> Valid Until Date

<CRYPTO\_IDX> Crypto Index.

#### 8.6.1.6.15 ISMS\_INFO\_PRODUCT\_WITHDRAWN\_NOTIFICATION

This is used to inform AMS that a product (IPE) has been withdrawn from service.

This packet will contain the following values that map to the IPEs Accepted Table in an ISAM.

<IIN> Product's IIN

<OID> Product's OID

<TYP> Type

<PTYP> PType

<IPE\_FORMAT\_REVISION> IFR

<KID> Key Identity

<DESCRIPTION> ISMS's Description of product

#### 8.6.2 Managed ISAMs

Control of the ISAM / HSAM asset base is the prime purpose of the AMS. As detailed in clauses 8.3 and 8.4, the AMS either directly or indirectly controls the Acceptance and Capability Criteria within its ISAM population. Data transfer between the AMS and ISAMs / HSAMs under its control is via:

• ISAM Security Files	(used to transfer data to an ISAM)
• ISAM Security Acknowledgements	(used by ISAM to acknowledge the above)

##### 8.6.2.1 ISAM Security Files

ISAM Security Files originate either from the ISMS when the data within said file relates to centrally controlled tables; or from the AMS when the data relates to a locally controlled table. In the former case the AMS only acts in a routing capacity for the Security Files.

The data within the Security File is encrypted and sealed by the originating node (ISMS or AMS). See ITSO TS 1000-8 for details of the ISAM Security File.

### 8.6.2.2 ISAM Security Acknowledgements

ISAM Security Acknowledgements originate from an ISAM / HSAM. They are destined to the node that originated the associated ISAM Security File (i.e. either the ISMS or the AMS).

The data within the HSAM / ISAM generated security acknowledgement is encrypted and sealed by the originating node. See ITSO TS 1000-8 for further details.

### 8.6.3 Managed POSTs

As detailed in clause 8.5 the AMS shall control the POST configuration data stored within POSTs. Data transfer between the AMS and POST uses the message processor in the HOPS and the following types of messages:

• Class 2 Parameter Table messages	(used to transfer data to a POST)
• Class 0 Acknowledgements	(used by POST to acknowledge the above)

See ITSO TS 1000-3 and ITSO TS 1000-6 for details of the Parameter Table messages.

### 8.6.4 Asset administrator

The AMS shall provide an interface that allows the asset administrator (the human operator of the AMS) to carry out all required user functions in an obvious and efficient manner. These functions shall include:

• Setting up and managing of general ISAM / HSAM data	(see clause 8.2.1)
• Setting up and managing of POST allocation	(see clause 8.2.2)
• Setting up and managing of HOPS allocation	(see clause 8.2.3)
• Setting up and managing locally controlled Acceptance and Capability Criteria tables	
• Setting up and managing indexed links between tables	
• Display console for ISMS Information Packets	

Where the AMS supports ISAM Logical Groups, then the interface shall support the setting up and management of Logical Groups.

## 8.7 Functionality

This clause defines the required AMS functionality to support the following:

- Installation / commissioning of ISAMs
- Create ISAM Physical Groups
- Change ISAM Physical Groups
- Take an ISAM out of service
- Reinststate an ISAM to service
- Make changes to ISAM Data
- Introduction of new product into scheme
- Withdrawal of a product

- Enabling of a new Customer Media platform
- Update of Directory keys by ITSO Registrar
- Update of Transaction keys by ITSO Registrar
- Support of regular key rollover
- Removal of an ITSO member
- Change ISAM password parameters
- Change storage of transactions parameters

### **8.7.1 Installation / commissioning of ISAMs**

The AMS shall carry out the following sequence of tasks:

Stage 1: Get and assign a valid ID to the ISAM

- This is likely to be done by a fulfilment bureau

Stage 2: Create the standard Acceptance and Capability Criteria tables

- Generate the ISAM Security Files required to create the required tables
- Receive and process the ISAM Security Acknowledgements arising in response to the above

Stage 3: Populate the centrally controlled Acceptance and Capability Criteria tables

- Generate the ISMS Security Requests required to populate the tables created
- Forward on to the ISAM in question any ISAM Security Files received from the ISMS as a result of the above request
- Receive, and send on to the ISMS, the ISAM Security Acknowledgements arising in response to the above

Stage 4: Populate the locally controlled Acceptance and Capability Criteria tables

- Generate the ISAM Security Files required to populate the required tables
- Receive and process the ISAM Security Acknowledgements arising in response to the above

### **8.7.2 Create ISAM Physical Groups**

The AMS shall carry out the following sequence of tasks:

Stage 1: Create Physical Group and assign ISAMs:

- Create the required Physical Group, identify said Physical Group and assign one or more ISAMs to the Physical Group

Stage 2: Create any required Acceptance and Capability Criteria table(s):

- Generate the ISAM Security Files required to create the required tables
- Receive and process the ISAM Security Acknowledgements arising in response to the above

Stage 3: Update the centrally controlled Acceptance and Capability Criteria tables:

- Generate the ISMS Security Requests required to update the ISMS controlled tables
- Forward on to the ISAM in question any ISAM Security Files received from the ISMS as a result of the above request
- Receive, and send on to the ISMS, the ISAM Security Acknowledgements arising in response to the above

Stage 4: Update the locally controlled Acceptance and Capability Criteria tables:

- Generate the ISAM Security Files required to update the AMS controlled tables



- Receive and process the ISAM Security Acknowledgements arising in response to the above

### **8.7.3 Change ISAM Physical Group**

The AMS shall carry out the following sequence of tasks:

Stage 1: Add / delete ISAM from Physical Group:

- Add or remove ISAMs from the Physical Group in question

Stage 2: Inform the ISMS of the inventory change:

- Generate the required ISMS Information Request and send it to the ISMS

Stage 3: Create any required Acceptance and Capability Criteria table(s):

- Generate the ISAM Security Files required to create the required tables
- Receive and process the ISAM Security Acknowledgements arising in response to the above

Stage 4: Update the centrally controlled Acceptance and Capability Criteria tables:

- Generate the ISMS Security Requests required to update the ISMS controlled tables
- Forward on to the ISAM in question any ISAM Security Files received from the ISMS as a result of the above request
- Receive, and send on to the ISMS, the ISAM Security Acknowledgements arising in response to the above

Stage 5: Update the locally controlled Acceptance and Capability Criteria tables:

- Generate the ISAM Security Files required to update the AMS controlled tables
- Receive and process the ISAM Security Acknowledgements arising in response to the above

### **8.7.4 Take an ISAM out of service**

Stage 1: Update status of ISAM in local database:

- Change the state of the ISAM as required (see clause 8.2.4)

Stage 2: Inform the ISMS of the inventory change:

- Generate the required ISMS Information Request and send it to the ISMS

Stage 3: Update ISAM:

- Generate the ISMS Security Requests required to update the ISMS controlled tables
- Forward on to the ISAM in question any ISAM Security Files received from the ISMS as a result of the above request
- Receive, and send on to the ISMS, the ISAM Security Acknowledgements arising in response to the above

### **8.7.5 Reinstate an ISAM into service**

Stage 1: Update status of ISAM in local database:

- Change the state of the ISAM as required (see clause 8.2.4)

Stage 2: Inform the ISMS of the inventory change:

- Generate the required ISMS Information Request and send it to the ISMS

Stage 3: Update ISAM:

- Generate the ISMS Security Requests required to update the ISMS controlled tables

- Forward on to the ISAM in question any ISAM Security Files received from the ISMS as a result of the above request
- Receive, and send on to the ISMS, the ISAM Security Acknowledgements arising in response to the above

#### **8.7.6 Make changes to ISAM Data**

Stage 1: Update the centrally controlled Acceptance and Capability Criteria table:

- Generate the ISMS Security Requests required to update the required ISMS controlled table
- Forward on to the ISAM in question any ISAM Security Files received from the ISMS as a result of the above request
- Receive, and send on to the ISMS, the ISAM Security Acknowledgements arising in response to the above

The ISMS may request that the AMS carry out this operation by use of an ISMS-AMS Information Packet. If this is the case then the AMS shall execute the operation in a timely manner in line with the obligations defined by the ITSO Business Rules.

#### **8.7.7 Introduction of new product into scheme**

Stage 1: Create any required Acceptance and Capability Criteria table(s) and the Embodiment parameters:

- Generate the ISAM Security Files required to create the required tables
- Receive and process the ISAM Security Acknowledgements arising in response to the above

Stage 2: Update the centrally controlled Acceptance and Capability Criteria tables:

- Generate the ISMS Security Requests required to update the ISMS controlled tables
- Forward on to the ISAM in question any ISAM Security Files received from the ISMS as a result of the above request
- Receive, and send on to the ISMS, the ISAM Security Acknowledgements arising in response to the above

Stage 3: Update the locally controlled Acceptance and Capability Criteria tables:

- Generate the ISAM Security Files required to update the AMS controlled tables
- Receive and process the ISAM Security Acknowledgements arising in response to the above

The ISMS may request that the AMS carry out this operation by use of an ISMS-AMS Information Packet. If this is the case then the AMS shall execute the operation in a timely manner in line with the obligations defined by the ITSO Business Rules.

#### **8.7.8 Withdrawal of a product**

Stage 1: Update the centrally controlled Acceptance and Capability Criteria tables:

- Generate the ISMS Security Requests required to update the ISMS controlled tables
- Forward on to the ISAM in question any ISAM Security Files received from the ISMS as a result of the above request
- Receive, and send on to the ISMS, the ISAM Security Acknowledgements arising in response to the above

Stage 2: Update the locally controlled Acceptance and Capability Criteria tables:

- Generate the ISAM Security Files required to update the AMS controlled tables
- Receive and process the ISAM Security Acknowledgements arising in response to the above

The ISMS may request that the AMS carry out this operation by use of an ISMS-AMS Information Packet. If this is the case then the AMS shall execute the operation in a timely manner in line with the obligations defined by the ITSO Business Rules.

### 8.7.9 Enabling of a new Customer Media platform

Stage 1: Create any required Acceptance and Capability Criteria table(s):

- Generate the ISAM Security Files required to create the required tables
- Receive and process the ISAM Security Acknowledgements arising in response to the above

Stage 2: Update the centrally controlled Acceptance and Capability Criteria tables:

- Generate the ISMS Security Requests required to update the ISMS controlled tables
- Forward on to the ISAM in question any ISAM Security Files received from the ISMS as a result of the above request
- Receive, and send on to the ISMS, the ISAM Security Acknowledgements arising in response to the above

The ISMS may request that the AMS carry out this operation by use of an ISMS-AMS Information Packet. If this is the case then the AMS shall execute the operation in a timely manner in line with the obligations defined by the ITSO Business Rules.

### 8.7.10 Update of Directory keys by ITSO Registrar

Stage 1: Update the centrally controlled Acceptance and Capability Criteria tables:

- Generate the ISMS Security Requests required to update the ISMS controlled tables
- Forward on to the ISAM in question any ISAM Security Files received from the ISMS as a result of the above request
- Receive, and send on to the ISMS, the ISAM Security Acknowledgements arising in response to the above

The ISMS may request that the AMS carry out this operation by use of an ISMS-AMS Information Packet. If this is the case then the AMS shall execute the operation in a timely manner in line with the obligations defined by the ITSO Business Rules.

### 8.7.11 Update of Transaction keys by / HSAM Registrar

Stage 1: Update the centrally controlled Acceptance and Capability Criteria tables:

- Generate the ISMS Security Requests required to update the ISMS controlled tables
- Forward on to the ISAM in question any ISAM Security Files received from the ISMS as a result of the above request
- Receive, and send on to the ISMS, the ISAM Security Acknowledgements arising in response to the above

The ISMS may request that the AMS carry out this operation by use of an ISMS-AMS Information Packet. If this is the case then the AMS shall execute the operation in a timely manner in line with the obligations defined by the ITSO Business Rules.

### 8.7.12 Support of regular key rollover

Stage 1: Update the centrally controlled Acceptance and Capability Criteria tables:

- Generate the ISMS Security Requests required to update the ISMS controlled tables
- Forward on to the ISAM in question any ISAM Security Files received from the ISMS as a result of the above request
- Receive, and send on to the ISMS, the ISAM Security Acknowledgements arising in response to the above

The ISMS may request that the AMS carry out this operation by use of an ISMS-AMS Information Packet. If this is the case then the AMS shall execute the operation in a timely manner in line with the obligations defined by the ITSO Business Rules.

### 8.7.13 Removal of an ITSO member

Stage 1: Update the centrally controlled Acceptance and Capability Criteria tables:

- Generate the ISMS Security Requests required to update the ISMS controlled tables
- Forward on to the ISAM in question any ISAM Security Files received from the ISMS as a result of the above request
- Receive, and send on to the ISMS, the ISAM Security Acknowledgements arising in response to the above

Stage 2: Update the locally controlled Acceptance and Capability Criteria tables:

- Generate the ISAM Security Files required to update the AMS controlled tables
- Receive and process the ISAM Security Acknowledgements arising in response to the above

The ISMS may request that the AMS carry out this operation by use of an ISMS-AMS Information Packet. If this is the case then the AMS shall execute the operation in a timely manner in line with the obligations defined by the ITSO Business Rules.

### 8.7.14 Change ISAM password parameters

Stage 1: Update the locally controlled Acceptance and Capability Criteria tables:

- Generate the ISAM Security Files required to update the AMS controlled tables
- Receive and process the ISAM Security Acknowledgements arising in response to the above

### 8.7.15 Change storage of transactions parameters

Stage 1: Update the locally controlled Acceptance and Capability Criteria tables:

- Generate the ISAM Security Files required to update the AMS controlled tables
- Receive and process the ISAM Security Acknowledgements arising in response to the above

### 8.7.16 ISAM Parameter Table Request and Response message codes 080A and 080B

These messages allow one or more ISAM Parameter Table files to be read from the ISAM and returned to the (first line) HOPS. The HOPS requests one or more files using message code 080A. The POST shall return the requested files together with a status code for each file requested using message code 080B.

This functionality shall only be used for specific ad hoc queries, not routinely. Only the required tables shall be requested, so as to minimise the size of the response message.

In circumstances where the HOPS receives a Negative Acknowledgement to the 080A message, it shall resend the message. After three failed attempts the HOPS shall highlight the issue to the system operators for manual intervention.

## **9. Services**

### **9.1 Audit Trail**

The HOPS shall provide an audit trail facility with the following capabilities:

- Audit trail of changes to HOPS data
- Error log
- Journal

All data and events recorded shall be stamped with the date and time of the event, together with the identity of the currently logged-on user where appropriate.

The Audit trail of changes to HOPS data shall:

- Record details of any changes to ITSO accounts - ISA & IPA creation, deletion or changes
- Record details of any changes to HSAM configuration
- Record details of any changes to AMS data files
- Be protected from any modification including addition, modification, renaming, moving or deletion
- Be protected from unauthorised access of any kind

### **9.2 Error Log**

The HOPS shall record errors in the error log, and mark each entry with an error type.

### **9.3 Journal**

The HOPS shall record all HOPS events in the Journal, including but not limited to:

- All HOPS data modification events
- Processing summaries
- Start-up dates and times
- ISAM installation, removal or changes within the HOPS
- User sign-on and off
- AMS activities
- HOPS software module upgrades/installations if this can be tracked electronically
- Modifications to the user permissions system data store
- Modifications to HOPS configuration

### **9.4 Query Facility**

The HOPS shall provide a search and reporting facility for the Audit Trail, Error Log and Journal based on but not of necessity limited to the following criteria:

- Date range
- Time range
- Event type
- Data store type

- Error type
- Logged on user identity
- Other criteria as required by the scheme
- A combination of the above

The search and reporting facility shall provide optional file output of results, and shall use XML format for said output files.

### **9.5 ITSO Regulation Compliance Monitoring.**

The HOPS shall provide a set of services to enable an external governance system mandated by the ITSO Operators Licence to assess compliance with the ITSO Operating Licence.

Said services shall include a facility to transmit compliance information automatically to said external governance function.

### **9.6 Security Monitoring.**

The HOPS shall provide a set of services to enable the HOPS operator and an external governance system mandated by the ITSO Operators Licence to detect security breaches.

Said services shall include the requirements in ITSO TC 1000-7, clause 5, Security Architecture.

Said services shall include a facility to automatically transmit information generated to said external governance function.

### **9.7 User Access Control**

The HOPS shall provide a User Permissions system in order to:

- Provide business entities with access to their own data, and to other data subject to commercial agreements;
- Prevent unauthorised access to data.

For each type of data entity, the HOPS shall provide separate access permissions for:

- Read
- Update
- Create
- Delete functions

Said access permissions shall be able to be set according to:

- OID
- TYP
- PTYP
- Individual user identity

The HOPS shall allow each HOPS user to access one or more OID/TYP/PTYP combinations if so required.

Said permissions shall be stored in such a manner that unauthorised access, deletion or modification is not possible. A supervisor permission shall be provided for the purposes of modifying to permissions.

### **9.8 Data Backup and Archiving**

The HOPS shall provide facilities for:

- Data backup
- Restore from backup
- Data archive
- Retrieval of archived data by data query tools
- Restore from archive

All HOPS data shall be stored in the backup and archive stores.

Archived data shall be available for immediate retrieval as and when required.

Archived data shall be retained:

- For a minimum period of 2 years and 6 months from the commissioning date for any new HOPS;
- And thereafter for a minimum period of 1 year 4 months.

## **9.9 System Clock**

Where the HOPS provides a system clock function, the clock shall be synchronised to within 1 second of an internationally recognised time source.